

cima[®]

ATOMIZZATORI-IMPOLVERATORI



Link

Operation and maintenance instructions

Dear Customer, thank you very much!
We want to congratulate with you, for having chosen a **cima** sprayer.

Your choice shows the wisdom of the well-informed Purchaser, aware of the fact, that the required features of quality, technique and reliability must be satisfied at the right price!

Our continuous engagement in R&D and in testing our machines allows us to realize products able to offer the best performances, a high reliability and a great easiness of use at the same time !

Our first goal, is to get our Customers happy for having met us!

The "Spare parts catalogue" of this sprayer/sprayhead is available in the "restricted area" on website www.cima.it.

In order to accede, use:

User name: **sprayer**
Password: **844719KE**

Articulated sprayer *Link*

Model:

Serial Number:

(Publication N° LUM-LINK-07-EN)

OPERATION AND MAINTENANCE INSTRUCTIONS

© CIMA S.P.A. 1996 - 2017 Private property.

Any reproduction, even if partial, is forbidden if not preventively authorized in writing by the Cima S.p.A. company.

cima[®]

Loc. Molino Quaroni n.7, Montù Beccaria - PV - (ITALY)
Tel. +39.0385.246636 - www.cima.it

LISTING OF VALID PAGES

This publication consists of 100 pages, subdivided as follows:

N° OF PAGE	REVISION	BASE
from I to VI	07	January 2017
from 1 to 4	07	January 2017

ADDITIONAL RECORDS AND VARIANTS

REVISION	DESCRIPTION
00	First Edition, March 2001
01	Second Edition, January 2002
02	Third edition, March 2002
03	Fourth edition, July 2003
04	Fifth edition, January 2009
05	Sixth edition, March 2001
06	Revision, April 2012
07	Revision, January 2017
09	
10	

INDICE GENERALE

1	FOREWORD.....	1
1.1	CHECKS TO BE CARRIED OUT AT MATERIAL RECEPTION	1
1.2	PUBLICATION IDENTIFICATION.....	1
1.3	ATTACHED PUBLICATIONS.....	1
1.4	PURPOSE OF PUBLICATION	1
1.5	REFERENCE TO REGULATIONS.....	2
1.6	USING THE MANUAL.....	2
1.7	UPDATES.....	2
2	GLOSSARY	3
2.1	TERMINOLOGY	3
2.2	ABBREVIATIONS.....	3
2.3	DECALS.....	3
3	GENERAL INFORMATION.....	8
3.1	MACHINE IDENTIFICATION.....	8
3.2	TECHNICAL ASSISTANCE	8
3.3	SAFETY NOTICES.....	8
3.3.1	General	8
3.3.2	Precautions against the fires.....	9
3.4	SAFETY SYSTEMS	10
3.5	HANDLING OF AGRO-CHEMICALS	10
3.5.1	Storage	11
3.5.2	Specific equipment.....	11
3.5.3	Disposal of empty containers and agro-chemicals residues.....	11
3.5.4	Personal Protective Equipment (PPE)	12
4	MACHINE'S STRUCTURAL ANALYSIS.....	13
4.1	FRAME.....	14
4.2	FAN SERVO AMPLIFIER.....	18
4.3	HYDRAULIC CIRCUIT.....	19
4.3.1	Operating principle	19
4.3.2	Hydraulic circuit components	23
4.4	TECHNICAL DATA	37
4.4.1	Sprayer dimensions and weights	37
4.4.2	Weight of accessories	38
4.4.3	Centrifugal pump CD32	40
4.4.4	Filters	41
4.4.5	Tanks.....	41
4.4.6	Fans	41

5	COUPLING MODALITIES	42
5.1	HITCHING TO THE TRACTOR	42
5.2	MOUNTING OF THE TRANSMISSION SHAFT	43
5.3	INSTALLATION OF REMOTE CONTROLS	43
5.3.1	Electrical control panel - E10	43
5.3.2	Manual 2-tap distributor - P9 (for the versions where foreseen)	45
5.3.3	E.P.A. Control Unit	45
6	DISTRIBUTION DEVICES	46
7	ACCESSORIES	47
7.1	FILLING PIPE	47
7.2	HYDRAULIC SWIVELLING DEVICE	47
7.3	ROTARY BLADES' HYDRAULIC MIXER (PATENT N° 1295858)	48
7.5	REAR LIGHTS KIT	48
7.6	E.PRESSURE ELETTROREGULATOR	48
7.7	E.P.A. KIT - DELIVERY PROPORTIONAL ADVANCEMENT	49
8	FILLING	50
8.1	FOREWORD - USE OF THE FAN DISENGAGEMENT	50
8.1.a	Disengagement of the fan	50
8.1.b	Fan engagement to perform the treatment	51
8.2	FILLING THROUGH POURING FROM THE TOP	51
8.3	FILLING WITH THE SPECIFIC PIPE	52
9	AGITATION	55
10	OPERATING PROCEDURES	55
10.1	PRELIMINARY OPERATIONS TO TREATMENT	55
10.2	PREPARATORY OPERATIONS TO TREATMENT	56
10.3	THE TREATMENT	57
10.4	PROCEDURE TO WASH THE HYDRAULIC CIRCUIT	58
10.5	END OF TREATMENT - STORAGE	60
10.5.1	Daily	60
10.5.2	End of seasonal cycle	61
11	TANK AND HYDRAULIC CIRCUIT DRAINING	63
12	LIFTING AND TRANSPORT	64
12.1	LIFTING AND TRANSPORT OF THE SPRAYER	64
12.1.1	Trailed cart disengagement	64
12.1.2	Lifting of the fan servo amplifier assembly	66

12.1.3 - Lifting of the trailed cart.....	66
13 MAINTENANCE OPERATIONS	67
13.1 LUBRICATION.....	67
13.2 FAN SHAFT SUPPORT OIL LEVEL CHECK.....	68
13.3 FAN SHAFT SUPPORT OIL REPLACEMENT.....	68
13.4 CLEANING OF FILTER'S CARTRIDGE.....	69
13.5 FAN BELT TENSIONER	69
13.6 PUMP BELT TENSIONER	70
13.7 MAIN TANK FASTENING BELT	70
13.8 TABLE OF MAINTENANCE OPERATIONS.....	71
14 FAULTS FINDING	72
15 REPAIRS ALLOWED	75
15.1 REPLACEMENT OF PUMP CONTROL BELT	75
15.2 REPLACEMENT OF ELECTRICAL PANEL'S FUSES	76
15.3 PRESSURE GAUGE REPLACEMENT	76
15.4 INSPECTION AND CLEANING PUMP FILTER.....	77
15.5 TANK LEVEL GAUGE CLEANING.....	78
15.6. CHECK HYDRAULIC DELIVERY	79
15.6.1 Check with flowmeter.....	79
15.6.2 Check without flowmeter.....	80
15.7 TANK REMOVAL OR REPLACEMENT	81
15.8 REPLACEMENT LAMPS REARLIGHTS.....	82
16 INTEGRATIVE DIAGRAMS.....	83
16.1 HYDRO-PNEUMATIC DIAGRAM.....	83
16.2 WIRING DIAGRAM	87
17 NOISE LEVEL.....	92
18 ATTACHMENT: DECLARATON OF CONFORMITY	93
19 WARRANTY.....	94
19.1 GENERAL INFORMATION.....	94
19.2 REPORTING DEFECTS IN GOODS	94
19.3 TO PASS SAFETY INFORMATION.....	94
19.4 VALIDITY AND ACCEPTANCE	94

1.1 CHECKS TO BE CARRIED OUT AT MATERIAL RECEPTION

At reception of the machine, make sure that this one is complete and in good condition in every part. If any damaged parts are found out, timely inform about that the machine Distributor, or directly contact C.I.M.A. SpA.

Upon receipt of the machine, expressly verify the following conditions:

- that the machine is delivered assembled in all its parts, and that the equipment fully complies with the requested configuration (that procedure is necessary, because for overall dimensions' requirements the machine is often partially disassembled during the transport);
- that the connections are correctly mounted;
- that the cable clamps are correctly tightened, as well as all the fittings and connections;
- that all the protections are both present and firmly fastened;
- that the oil level inside the fan support is correct;
- that the fan, the fan protection casing or other parts of the machine ARE NOT damaged because of any bumps suffered during the transport.

1.2 PUBLICATION IDENTIFICATION

The "OPERATION AND MAINTENANCE INSTRUCTIONS" manual is an integrative part of the sprayers. It is identified by a Publication No. located on the frontispiece, and through which the document can be identified, traced and/or subsequently referred to.

The information elements contained herein are updated as at the date of publication. C.I.M.A. S.p.A. reserves the right to modify its machines without notice, with the purpose of applying technical enhancements, and it declines all responsibility for possible omissions from the publication.

All rights are reserved. No parts of this book may be reproduced or utilized in any form or by any means, electronic or mechanical, including photocopying, recording, or by any information storage and retrieval system, without permission in writing by C.I.M.A. S.p.A..

1.3 ATTACHED PUBLICATIONS

- Spare parts catalogue, available in the "restricted area" on website www.cima.it (see on the inside cover);
- Distribution devices, "Operation and maintenance instructions";
- Distribution devices, "Spare parts catalogue";
- "Low Volume - Instructions for sprayer adjustment".

1.4 PURPOSE OF PUBLICATION

All indications contained in this manual are aimed at the user of the sprayer.

The duration of the machine and its operation, the operator's safety and the respect for the environment are dependent upon scrupulous observance of the stated norms.

Before making use of the sprayer, the user must read, understand and abide by all regulations listed in this manual.

1.5 REFERENCE TO REGULATIONS

This manual was set out conforming to the regulations contained in following documents:

- Directive 2006/42/CE: Attachment 1 point 1.7.4;
- UNI 10653: Technical Documentation;
- UNI 10893: Technical Documentation.

1.6 USING THE MANUAL

Read every part of this manual, paying attention to the WARNING and DANGER indications both on the text and on the machine or on components.

All operations suggested by the manual will have to be followed with the utmost care and only after having understood the negative consequences of improper usage.

The following “**symbols**” are used within the text in order to highlight and visually identify the importance of the various types of information:



Indicates important additional information.



Non observance can result in permanent damage to the sprayer.



Highlights possibly dangerous situations to people.

The manual, with relevant attachments and possible integrating issues, must be kept with the utmost care and must always be complete, integer and legible in every part. Should it be mislaid it is imperative to immediately request a duplicate from C.I.M.A. S.p.A.

Should the decals originally applied on the machine be mislaid, damaged or become incomprehensible, they should be promptly replaced.

For every type of distribution device (Head) delivered with the sprayer, a specific user and maintenance manual is attached. All the head manuals must always accompany the one of the machine.



- The manual must always be kept for the sprayer's whole operational life.
- Any modification received must be permanently inserted in this publication.
- The manual must be ceded with the sprayer should this be sold.

1.7 UPDATES

Any amendments or additions that C.I.M.A. S.p.A. may send the sprayer's owner will be accompanied by the necessary instructions to be included with this publication, becoming an integral part of it.

2 GLOSSARY 2

2.1 TERMINOLOGY

The terms FRONT, REAR, RIGHT and LEFT utilised in this publication refer to the sprayer as seen by an operator from behind the operative unit along the drive line and facing it: **the rear part** of the machine is that closest to the operator and **the front part** is the one that gets attached to the tractor.

2.2 ABBREVIATIONS

cm	centimetres
g	grams
h	hour
ha	hectare
ha/h	hectare per hour
kg	kilogram
kg/cm ²	kilograms per square centimeter (atmosphere)
km	kilometre
km/h	kilometres per hour
l	litres
l/h	litres per hour
l/min	litres per minute
Lm	width in metres
m	metre
Mesh	N° of meshes per linear inch
Micron	1/1000 of millimetre
mm	millimetres
PPE	Personal Protective Equipment
PTO	power take-off
RPM	revs per minute
s	seconds

2.3 DECALS

The safety and use/maintenance decals are applied to the machine are described in the following paragraph.



Every decal is marked with its part number, in case it needs to be replaced.

The arrangement of the adhesives on the machine is shown in the following pictures.

Safety decals



- STOP THE ENGINE AND REMOVE THE KEY FROM THE TRACTOR'S CONTROL PANEL BEFORE CARRYING OUT ALL MAINTENANCE OR REPAIR OPERATIONS
- CONSULT THE USER AND MAINTENANCE MANUAL BEFORE USING OR INTERVENING ON THE MACHINE

95001



- CONSULT THE USER AND MAINTENANCE MANUAL BEFORE USING THE MACHINE
- DANGER OF CONTAMINATION BY CONTACT OR POISONOUS PRODUCTS INHALATION
- IT IS FORBIDDEN TO GET INTO THE TANK!

95098



- DANGER OF SPRAYS: KEEP AT A SAFE DISTANCE
- DANGER, PARTS IN MOTION. BEFORE REMOVING PROTECTION GUARDS, STOP THE TRACTOR, REMOVE THE KEY FROM THE TRACTOR'S CONTROL PANEL AND ENSURE THAT ALL MOVING PARTS HAVE STOPPED.

95099



- NO HAND-WASHING TANK

95008



- DANGER: GLOVES MUST BE USED TO EMPTY THE TANK

95009



- BEFORE UTILISING THE RELEASE DEVICE, STOP THE TRACTOR, REMOVE THE KEY FROM THE TRACTOR'S CONTROL PANEL AND ENSURE THAT THE FAN HAS STOPPED.

95015



- OPERATING SPEED OF THE DRIVE OUTLET (PTO): 540 RPM

95010



- LIFTING: USE ONLY SUITABLE BELTS AND TO HOOK AT THE POINT INDICATED

95021

Use and maintenance decals




95079

- CHECK THE OIL LEVEL EVERY 8 HOURS:
FAN SHAFT BEARINGS.




95024

- LUBRICATE EVERY
200 HOURS:
SUPPORT FOOT with
crank regulation




95115

- GREASE YEARLY:
FAN TIGHTENER SUPPORT AND
FREEWHEEL




95054

- GREASE EVERY 200 HOURS:
WHEEL HUBS AND ARTICULATED
JOINTS



95080

- INDICATION ON THE
OPERATION OF THE
3-WAY TAP (P2)



95100

- INDICATION ON THE
OPERATION OF MIXER
TAP (P12)



95086

- INDICATIONS ON
THE OPERATION
OF THE PLANT-
WASHING TAP (P15)



- HAND
WASHING
TANK TAP
Imprint next to
the tap.



95019

- FILL ONLY WITH
CLEAN WATER
Hand washing tank filler,
Rinsing tank filler.




95065

- WARNING: NEVER OPERATE
THE SPRAYER WITHOUT
LIQUID IN THE TANK



95058

- INDICATION OF
THE CHEMICAL
EMPLOYED
FOR THE
TREATMENT



95081



95060

- TIRES PRESSURE



95059

- HOOKING POINT
FOR THE LIFTING
OF THE MACHINE

Positioning of the safety, use and maintenance decals

NOTE: The numbers with the asterisk (*) indicate the adhesives relevant either to optional components or to accessories to be applied **ONLY** on the models and versions on which it is foreseen.

TATTAMENTO CON:
TREATMENT WITH:
TRAITEMENT AVEC:
TRATAMIENTOS CON:

95102

95059

95054

SUPPORT FOOT

95010

95080

95021

95005

95019

95008

95015 (*)

FREE WHEEL

95115

95059

95019

95009

FAN TIGHTENER SUPPORT

95115

95001

95010

A
Posizione lavoro
Working position
Position de travail
Posición de trabajo

B
Miscelazione
Mixing
Mélange
Mezclas

C
Chiusura
Close
Fermé
Cerrado

95100

95102

A POSIZIONE LAVORO / POSITION DU TRAVAIL
WORK POSITION / POSITION DE TRAVAIL

B COLLEGAMENTO / COLLECAMENTO TUBO RIEPI
CONNECTION / DISCONNECTION TUBO DE REMPL.
CONEXION / DISCONEXION TUBO DE CARGA

C EQUIVAMENTO USAR / OBRAR / VELOC CUELLO Y PUNTA
DANS LE SENS D'AVANT / DIRECTION DE TRAVAIL / AVANCE

95080

MANCA SERVIZIO LUBRIFICAZIONE
LE RISPONDI DI LUBRIFICAZIONE MANUALE
MANQUE DES OILS MANUELS
FALTAN SERVICIOS DE LUBRIFICACION
FALTA SERVICIO DE LUBRIFICACION

95008

95015 (*)

FREE WHEEL

1 VOLTA L'ANNO
YEARLY - ANNUEL - ANNUAL

95115

95115

95019

95009

1 VOLTA L'ANNO
YEARLY - ANNUEL - ANNUAL

95115

95001

95010

95059

01680_1

95065

NON FARE MAI FUNZIONARE
L'UTILIZZAZIONE SENZA LIQUIDO
NEL SERBATOIO
PUMP MUST
NOT RUN DRY
NEVER FAIRE FONCTIONNER LE
PULVEUR SANS LIQUIDE DANS LE
RESERVOIR

95065

01680_1

95054

95054


95059

95019


95009

95001

95010



3.1 MACHINE IDENTIFICATION



3.2 TECHNICAL ASSISTANCE

C.I.M.A. S.p.A. is at the complete disposal of customers for any type of intervention. The names and addresses of its service network, both in Italy and in foreign countries, can be requested from:

C.I.M.A. S.p.A. - 27040 Montù Beccaria - Loc. Molino Quaroni (PV) - ITALIA
tel. +39-0385-246636 - fax +39-0385-246637
e.mail service@cima.it
GPS: 45°03'19.3" N - 9°18'22.1" E

3.3 SAFETY NOTICES

3.3.1 General



The personnel appointed to the use of the machine must have acquired an exhaustive knowledge of the same one and of the dispositions contained inside this publication, be able to properly interpret the symbols of the adhesives applied on the machine, and, in addition, perfectly know the safety and the work hygienic rules in force in the country where the machine itself is to be used.

All the preparation, use, maintenance, moving and transporting operations must be carried out of the regulations contained in this publication.



IT IS FORBIDDEN TO UTILISE THE SPRAYER FOR PURPOSES OTHER THAN FOR ITS INTENDED USE, SINCE IT WAS MANUFACTURED ONLY FOR SPRAYING AGRICULTURAL CROPS WITH ANTI-PARASITIC PRODUCTS.
ANY USE OTHER THAN THOSE DESCRIBED IN THE USE PERMITTED IS CONSIDERED AS NOT CONFORMING AND THEREFORE IS NOT PERMITTED.

It is necessary to scrupulously abide by the following general norms:

- check that the weight and power of the tractor are compatible with the sprayer to be used;
- verify that the tow capacity of the tractor is compatible with the total weight of the sprayer to be used;



On the identification plate, the full-load weight (PESO T.) of the machine is indicated, measured WITHOUT the distribution device, and WITHOUT the accessories possibly installed.

In order to calculate the weight on the hoister in operative conditions (at full load), add to the WEIGHT OF THE FAN SERVO AMPLIFIER (see Paragraph 4.4.1 - Sprayer dimensions an weights), the WEIGHT OF THE DISTRIBUTION DEVICE which is used (see “Distribution devices – Use instructions” manual), THE WEIGHT OF THE INSTALLED ACCESSORIES (Par. 4.4.2) and THE 50% OF THE WEIGHT OF THE USED CARDAN SHAFT (see the relevant specific manual).

In order to calculate the towed weight in operative conditions (at full load), add to the weight indicated on the identification plate (PESO T.), the weight of the installed accessories (Par. 4.5.2 - Weight of the accessoires).

- before utilisation, check the correct tightening and securing of the machine's various components, paying particular attention to the safety protections and to the moving parts;
- only utilise protected cardan shafts provided with CE conformity certification. Carry out the assembly only if the drive outlets of both tractor and sprayer are equipped with the protection counter-guard;
- check that the cardan shaft is blocked by the appropriate anti-rotation chains;
- keep people and animals away from the machine before starting it up;
- don't wear articles of clothing that might get caught in moving parts;
- keep to a low speed while negotiating bumps or crossing ditches.
- during the use of the machine, the operator must have a sufficiently good visibility on the working areas, consequently it is recommended to keep both clean and efficient the cab windows and the rear-view mirrors;
- actuate the parking brake when the tractor is stopped on a slope and place the wedges behind the wheels of the railed cart;
- always stop the tractor's engine and actuate the parking brake before carrying out any operation on the sprayer;
- never leave the machine unguarded, when the key is inserted inside the tractor control panel;



- All maintenance and repair operations must be carried out only after having rinsed the tank and flushed the system.
- Before operating within the tank it is necessary to wash it thoroughly with clean water.
- The application of paints and/or solvents, the washing of closed environments and machinery as well as the utilisation of the air flow for purposes other than those expressly concerning the spraying of agro-chemicals is not permitted.
- It is forbidden to enter the tank.

3.3.2 Precautions against the fires

Don't approach either flames or heat sources to the machines. The materials used for manufacturing the machine itself are made by widely using oil derivatives: tanks, pipes, wheels, plastic components; besides, the presence of lubricants and of chemical product residuals make them potentially flammable.



- It is forbidden to use the machine within a potentially explosive environment.
- It is forbidden to perform welding operations if ammonium salts were previously used.


3.4 SAFETY SYSTEMS

All machine moving parts are suitably protected by guards and highlighted through the use of warning decals.



- It is forbidden to use the machine with these guards removed.
- Before removing the protection, stop the tractor's engine and remove the key from the control panel.

The pictures illustrate the machine's guarded parts:



THE OWNER AND/OR THE OPERATOR OF THE SPRAYER ARE NOT PERMITTED TO MODIFY THE STRUCTURE OR THE SPECIFIC OPERATION OF THE SPRAYER ITSELF. ANY REPAIRING INTERVENTION HAS TO BE CARRIED OUT EITHER AT THE DEALERS' OR AT THE C.I.M.A. S.p.A. AUTHORIZED WORKSHOPS, OTHERWISE ANY KIND OF WARRANTY IMMEDIATELY CEASES AND C.I.M.A. S.p.A. IS CLEARED OF ANY CONSEQUENT AND/OR IMPLIED RESPONSIBILITY.

3.5 HANDLING OF AGRO-CHEMICALS

The operator could become contaminated due to accidental spray, contact or inhalation of products or crop-spraying mixtures.

The environment could become polluted by mixture over-spills, puncturing of containers, uncontrolled storage of used and unwashed containers or spillage into waterworks.

In order to avoid these risks the preparation and filling operations must be carried out in suitably appointed and adequately equipped sites.



To use pesticides (purchase, transport, loading, treatment planning, mixture preparation, field transfer, treatment performance, ending treatment liquid waste management, equipment rinsing and waste disposal) you must follow the country rules.



Absolutely respect the rules on the label of the product used referring to the dose for hectar and to the compatibility of other products.

3.5.1 Storage

Fixed / stationary: the site used must be well ventilated and secured by lockable doors in order to prevent even accidental access by children or unauthorised persons.

Mobile: the carrier equipment must be properly locked and kept under conditions whereby access by children or unauthorised persons can be prevented during the absence of the operator. All full or partially utilised containers must be secured against tipping, falling or breakage during transportation.

Both types of storage must:

- have a suitable container for the storing of empty packaging materials should a specific storage area not be available;
- have a clean water supply readily available for washing, by means of a specific container or through connection to the waterworks system;
- have the use of fire extinguishers, should flammable products and substances be stored.



- All packages, whether whole or partially utilised, must be stored in their original packing and with the warning instructions clearly displayed and legible.
- The storage indications must always be scrupulously adhered to, as well as their utilisation and possible disposal as suggested on the product's original packaging.

3.5.2 Specific equipment

The site at which the preparation and filling out will take place must provide for:

- all the equipment necessary to the precise measuring of both the water quantity and the dose of product to be mixed in the tank at every filling;
- all the equipment and means useful to the preparation of the mixture and for the cleaning of the operator in case of contamination;
- all tools necessary to facilitate the direct introduction of the agro-chemicals in the tank;
- the allocation of clothing and specific equipment in order to avoid contamination by contact or inhalation during the whole operative phase of the intervention;
- the availability of proper equipment able to stop the uncontrolled spilling and flowing of the mixture;
- a retaining valve on the feed pipe when the filling of the tank takes place directly from the waterworks system.

3.5.3 Disposal of empty containers and agro-chemicals residues

Agro-chemicals are classified as "special" waste and their disposal must take place separately from "urban" wastes.



Empty packaging and contaminated containers to be done away with cannot be dispersed, burned or buried. The washing water for the cisterns and the tools utilised for the preparation of mixtures cannot be emptied on the ground, spilled into the sewage system or in waterways and rivers.

The disposal of special wastes is regulated by specific norms. In order to perform this operation it is necessary to obtain the relevant information from the Local Offices specifically appointed to rule on this subject. The non compliance with these regulations can cause considerable damage to persons and animals as well as polluting the environment.

3.5.4 Personal Protective Equipment (PPE)

The use of phytosanitary products might imply a more or less high chemical risk for the workers on the basis of the toxicity and the dangerous properties of the phytosanitary product, of the level and duration of the exposure, of the absorption level through the respiratory tract, the skin, the mucosa and the ingestive tract, as well as the way and frequency of the use.

The “personal protective equipment” (PPE) are equipment that all the users of the machine need to wear and hold in order to be protected by one or more risks that are capable to treat the security or healthy during the job.

Regarding the basic requirements, PPE have to:

- be suitable to the risks that have to be prevented, without causing major risks themselves;
- be suitable to the existing conditions on the workplace;
- consider the ergonomic (easily adaptable, easy to wear and safe) or health needs for any users;
- be adaptable to the user according to his/her needs.

The PPE for the protection against dangerous chemical agents used for the operations that concern the exposition to phytosanitary products , pertains to the third class (3rd class – 0000).



Use solely PPE equipped with the needed CE mark, in the scrupulous respect of the regulations in force in the country where the machine is in use and adequate to the phytosanitary product used.

It's needed to use the PPE in each of the following working stage:

- tank filling and addition of the phytosanitary product;
- spraying,
- calibration of the sprayer,
- draining and cleaning of the tank,
- phytosanitary product replacement,
- servicing.

The following must be worn:

- for the protection of the body (gloves, suits, boots),
- for the protection of the respiratory tract, of the head and of the eyes (helmet, masks, filters, glasses, hoods and headdresses).




Filters must be replaced following the producers' instructions, and in any case:

- in case a bad smell is noticed;
- in case a resistance to the respiratory function is noticed;
- at least once a year in case of occasional use.

For ALL PPE in use, follow the use instruction declared by the PPE producerse.


4 MACHINE'S STRUCTURAL ANALYSIS 4

The pictures indicate the position of the main components of the sprayer.




4.1 FRAME

The LINK trailer-mounted sprayer frame consists of two sections: the front section, supporting the fan-servo amplifier unit, and the rear one, supporting the main tank and the spray-line rinsing tank (for models on which it is foreseen).




The connection between the frame two sections is realized by means of a special articulated joint, which is integral with the frame front section and assures a completely free movement to both the frame sections.

The front section is directly coupled with the three points-hydraulic hoisting device of the tractor.



The Link 50 e 55 range frames can be coupled with the hydraulic hoisting devices of class "2". The piston pins' diameter measures 28,5 mm. The third point pin diameter measures 25 mm.

As it is possible to regulate the length of the coupling lower bars to the hydraulic hoisting device, the length of the coupling between the frame front and rear sections, the trailer axle and the track positions, the sprayer articulated joint can be exactly positioned **on half a way between the tractor rear axle and the trailer one**. On that condition, the trailer wheels exactly cover the same trajectory as the tractor wheels.




HOISTING DEVICE COUPLING LOWER FORKS

They are inserted in the articulated frame front section. Their position is regulated through the two lateral bolts, especially foreseen for this purpose.

- To be **length-regulated**, by 5 – 10 cm. displacements..



After every regulation, carefully tighten all the screws and the bolts concerned by the intervention.




AXLE

The axle is secured to the frame rear section by means of especially foreseen screws, allowing to regulate its position, in order to modify the sprayer trailer wheel base. The four holes machined on the fastening plate allow to select two different axle positions, by 5,75 cm displacements.

The wheels' axle shafts, inserted in the frame axle and locked by some special screws, allow to regulate the **track width**, in order to fit it to the intervention requirements.



After every regulation, carefully tighten all the screws and the bolts concerned by the intervention.



WHEELS. The wheels' hubs are equipped with grease nipples for the bearings lubrication (see Paragraph 13.1).

The tyres' size and the operating pressure are indicated at Paragraph 4.4.2.

BEARING FEET. They assure stability to the unit, when it isn't coupled to the tractor.




The sprayer HAS NEVER to be uncoupled from the tractor before having correctly positioned the bearing feet.




The BEARING FEET have always to be locked on "treatment position" during the unit operation.

The bearing feet can be fastened to the sprayer in 2 different positions, according with the different operational requirements::

Position A - front feet downwards and rear foot lowered: **THIS ALLOWS TO UNCOUPLE the tractor** and assures the sprayer stability, when it isn't coupled to the same one.



Position B - front feet vertically applied to the frame and rear foot lifted: it allows to use the sprayer, after that the same one was coupled to the tractor (**treatment position**).




THE RESPONSIBILITY OF THE REGULATION, ASSEMBLY AND DISASSEMBLY OPERATIONS OF THE HOISTING DEVICE COUPLING FORKS, OF THE AXLE AND OF THE WHEELS IS CHARGED TO THE OPERATOR, WHO HAS BOTH TO REALIZE AND TO ASSURE THE NECESSARY SAFETY CONDITIONS, IN ORDER TO PREVENT ANY POSSIBLE ACCIDENT.

4.2 FAN SERVO AMPLIFIER

It is positioned in the unit front section and protected by a plastic casing.

Servo amplifier

It is equipped with an automatic tensioner of the driving poly-V belts that keeps the belt tension constant, avoiding slipping and wear. **A overrunning clutch is included** between the Power Take-off of the servo amplifier and the fan control pulley (for versions on which it is foreseen). In case of sudden decelerations or unexpected engine stoppage, this allows the fan to continue its free rotation, thus avoiding extreme mechanical stresses to be transmitted to the drive members.




Centrifugal fan

The front-engaging clutch assembled on the fan shaft allows the operation of the centrifugal pump without the fan. (for versions on which it is foreseen).

An air intake predisposed on the casing external edge is connected, by means of a pipe equipped with a cock, to the tank inner agitator.

Through this tap it is possible to carry out or exclude pneumatic agitation.

The closed blades' impeller is sheet steel realized and dynamically balanced; the air intake opening on the casing is protected by a steel grating.




4.3 HYDRAULIC CIRCUIT

4.3.1 Operating principle


WORK – The tank (P1) contains the mixture that must be distributed to the area being treated. The tank (P1) is connected to the pump (P4) via 3-way tap (P2). With tap (P2) in position “A”- WORK and (P15) in position “c” - CLOSED, the mixture is drawn by the pump (P4) and sent to the pressure regulator (P5), and then through filter (P7) to the distribution device (sprayhead).

The regulator (P5), together with the position of the rotating disc regulator (P11), allows the sprayer’s supply pressure to be adjusted so that the desired distribution in litres/hectare is achieved. Excess liquid supplied by the pump through pipes (T3) and (T9) is conveyed into the tank to keep the mixture constantly agitated.




The delivery filter (P7) is located downstream of the regulator (P5) on the delivery to the distribution device (sprayhead). From the filter, the mixture travels through pipe (T4) to the electrical distributor (E9) (or manual P9, where envisaged) which, if open, enables the mixture to be distributed. The connection for pressure gauge (P8), which checks the distribution pressure, is fitted to the body of the filter (P7).

MIXING - Pipe (T6) connects the delivery of pump (P4), through tap (P12) to the powder mixer of the main filler (where envisaged). If necessary, close tap (P24) to increase the flow rate to the mixer.




CIRCUIT WASHING - Where envisaged, the circuit-washing tank (P17) is connected through tap (P15) to pump (P4).

When the pressure regulator (P5), or the electrical regulator (E5) (joystick on + for approx. 15 sec.), is completely closed, position tap (P2) to "B", tap (P12) to "C" and tap (P15) to "a" - OPEN to exclude the main tank and supply pump (P4) with clean water from the circuit-washing tank, enabling the distribution circuit to be washed even while the main tank is full or partially full.



FILLING (with filling pipe). The filling pipe (TR) (accessory) can be connected to the pump (P4) to fill the tank by collecting the water needed for the dilution of the phytosanitary products mixture from an external tank, from a well or from a canal/channel (in case provided for by the regulations in force in the country where the machine is in use).


- Legend
 P - E = hydraulic circuit components
 T = piping
 * = for versions with rinsing tank
 ▲ = for versions in which this is envisaged
 □ = optional on demand
 ○ = for versions without rinsing tank



FILLING with filling pipe


01692_8

4.3.2 Hydraulic circuit components



Versions with additional agitation pump

- Legend
 P - E = hydraulic circuit components
 T = piping
 * = for versions with rinsing tank
 ▲ = for versions in which this is envisaged
 □ = optional on demand




Hydraulic connections diagram

01692_10

Versions with E.P.A. (Delivery Proportional Advancement)

Legend

- P - E = hydraulic circuit components
- T = piping
- * = for versions with rinsing tank
- ▲ = for versions in which this is envisaged
- ◻ = optional on demand
- = for versions without rinsing tank




Hydraulic connections diagram

01692_11

Versions with E.P.A. and additional agitation pump

- Legend
P - E = hydraulic circuit components
T = piping
***** = for versions with rinsing tank
▲ = for versions in which this is envisaged



Hydraulic connections diagram

01692_12

P1. MAIN TANK


Polyethylene tanks of 800, 1000 and 1500 litre capacity.

Each tank is made up of:

- tank main filler, (BP) with a 400 mm diameter hinged cover, with breather pipe; Plastic cup-like filter: 302 mm external diameter, height 254 mm, powder mixing device (for versions in which this envisaged);
- supplementary tank filler with 250 mm diameter screw-type lid, for filling with clear water and plastic cup-like filter: external diameter 204 mm, height 240 mm;
- transparent level indicator external pipe with graduated scale, (One on the left-hand side of the tank L1 and one on the front side L2);
- double hydraulic agitation;
- pneumatic agitation;
- piston cock, positioned over the tank and connected through a pipe to the air inlet, which is placed on the fan casing, for opening/closing the pneumatic agitation.

P22. ADDITIONAL HAND-WASHING TANK

30-litre polyethylene tank, with external tap.



P2. 3-WAY LEVER TAP WITH DISCHARGE FITTING

Positioned on the pipe (T1), between the tank (P1) and the pump (P4), it is equipped with a closing plug of the discharge fitting, with the relevant safety chain.

The 3-way lever (P2) can be positioned as here following specified:

A - Treatment

The liquid gets out from the tank (P1) and is sucked by the pump (P4); this is the **NORMAL** operating position, which is used in order to carry out the treatment and/or to keep the mixing on. The discharge fitting is **closed**.

B - Filling

This position is used in order to fill the tank through the especially foreseen pipe, to be applied to the fitting on the pump (P4). It is closed the suction pump from the tank, the drain plug must be properly tightened and should NOT be removed. When the cock is on that position, it is moreover possible to remove the pump (P4), also when the tank is loaded.

C - Drainage

In this position, it is possible to empty: the tank (P1), the pump (P4) and all the pipes of the hydraulic circuit.



WARNING: the tank contains PHYTOSANITARY PRODUCTS. Discharge in an area equipped with catch basin and provide to draining in the scrupulous respect of the local regulations in force..

<p>(A) POSIZIONE LAVORO WORK POSITION</p>	<p>(B) COLLEGAMENTO / SCOLLEGAMENTO TUBO RIEMP. CONNECTION / DISCONNECTION FILLING PIPE CONEXION / DESCONEXION TUBO DE REMPL. CONEXION / DESCONEXION TUBO DE CARGA</p>
<p>(C) SVUOTAMENTO SERBATOI/POMPA TANK & PUMP DRAINING</p>	<p>VIDAGE CLVE ET POMPE DRENAJE DE TANQUE Y BOMBA</p>


00319

P21. NON-RETURN VALVE

It is located on the pump suction (P4)..

P4. CENTRIFUGAL PUMP

Fastened on the unit left front section, it is connected with the 3-way cock (P2) and with the pressure regulator (P5). The pump is provided by the suction side of a filter to prevent the accidental entry of foreign bodies in the pump body, such a possibility does not constitute a hazard and can only cause damage to the impeller shown by a drop in pressure reported by gauge



THE PUMP MUST NEVER RUN DRY

The water must be always in the pump : **ALWAYS** check this point carefully at the start up and during the functioning.

To avoid any damage to the pump:

- At the first filling and at every next filling after the hydraulic circuit draining, fill the tank with an appropriate quantity of water to fill the pump completely; to do so, remove the cap from the pump body and allow water into the tank until it comes out of the pump's filler; refit the cap on the filler.
- In order to control that the pump is not running dry, **AFTER** engaging the PTO, check that the pressure gauge (P8) shows **an operating pressure value above 0 (zero)**; otherwise, **STOP THE PTO IMMEDIATELY**.

P5. MANUAL PRESSURE REGULATOR

It is connected to the delivery filter (P7) and, through pipe (T3), to the tank (P1). It regulates the operating pressure, by controlling the return flow to the tank.

- **By closing it:** it reduces the return flow to the tank and therefore, the agitation of the mixture, and **INCREASES the operating pressure** and the capacity flow to the head (rotate the handle clockwise).
- **By opening it:** it increases the return flow to the tank and therefore, the agitation of the mixture, while **REDUCING the operating pressure** and capacity flow to the head (rotate the handle anti-clockwise).

E5. PRESSURE CONTROL ELECTRO-VALVE

(for versions in which this is envisaged)

It is connected to the delivery filter (P6) and to the tank (P1), through the pipe (T3). It adjusts the operating pressure checking the backflow into the tank.

- **Moving the joystick upwards (+)** on the electrical control gearbox, **the electrovalve closes**: in the tank both the backflow and the agitation decrease while **the values of the working pressure and the delivery to the sprayhead increase**.
- **Moving the joystick downwards (-)** on the electrical control gearbox, **the electrovalve open**: in the tank both the backflow and the agitation of the mixture increase while **the values of the working pressure and the delivery to the sprayhead decrease**.

In the E.P.A. versions, the pressure regulation is **automatically** controlled by the electronic control unit (see specific manual).

P7. FILTER

It is connected to pressure regulator (P5) and, through pipe (T4), to the distributor (E9/P9). The filter has a filtering capacity of 250 l/min., with a 32 mesh cartridge (white). The dirty cartridge causes the operating pressure chute. **This inconvenient is signalled by the pressure gauge**. Mounted on the feeding pipe, it only filters the delivery flow to the heads, by sensibly reducing the possibility for the cartridge to get obstructed. On the body of the filter there is an attack, with internal thread 1/4", to make a functional test of the gauge (P8).

P8. GAUGE

Glycerine-dipped, with dial from 0 to 6 Kg/cm² (atmosphere) – adjustments scale of **1/10 of atmosphere**, 100 mm diameter, class 1,6%; it is connected to filter (P7).




Set the working pressure, by acting on the regulator hand grip (P8), keeping the (P9) or (E9) opened, i.e. with the sprayhead running.

E8. TRANSDUCER OF THE DELIVERY PRESSURE

(for versions in which this is envisaged)


In the E.P.A. versions, the pressure transducer is connected to the delivery control computer. (see the specific manual).



E10. CONTROL UNIT


Electrically connected with the distributor with 2 motor-operated valves (E9) and with the tractor's power socket. The two lever switches that control the valves (E9) must be "ON" to open and "OFF" to close. The control unit is fitted with a bayonet support to be inserted into the bracket provided. This must be fastened to the tractor within reach of the driver. When the machine is not coupled to the tractor, it must be housed in the seat on the frame at the front of the machine.

Depending on the machine/sprayhead set-up, the control unit has 2 configurations:



STANDARD:



1. distribution solenoid valves ON/OFF control.



For versions WITH ELECTRICAL PRESSURE REGULATOR (E5):


1. distribution solenoid valves ON/OFF control;
2. pressure adjustment +/- control;
3. electrical diffusers operation (where envisaged).

The control unit has two sections for versions with 4 distribution SOLENOID VALVES: the top for controlling distribution from the upper diffusers (4) and the bottom, which can be in standard configuration (5) or with electrical pressure regulator (6) .



If the sprayer is equipped with a distribution device (sprayhead) fitted with hydraulic operation with 3 electro-hydraulic valves, in addition to the electrical control unit the machine will also be equipped with

the respective control units (see manual "Distribution devices - Operation and maintenance instructions")




01668_2

**CONTROL UNIT
WITH 3 ELECTRO-HYDRAULIC VALVES**

E9. ELECTROVALVES ASSEMBLY (with remote control)

It is connected with the feeding pipe (T4), the distribution pipes (T5) and the electrical unit (E10), which is fastened on the tractor. The solenoid valves open and close themselves, according with the action carried out on the electrical control unit switches.

In the E.P.A. versions, the controls of the cross section solenoid valves are situated on the electronic control unit (see specific manual).



01701


P9. MANUAL DISTRIBUTOR WITH 2 LEVER-OPERATED TAPS

(for versions in which this envisaged)

It connects the feeding pipe (T4) to the distribution piping (T5). It remote-controls the closing and opening of the pulverising. The mount bracket, supplied with the machine, must be secured to the tractor within the driver's reach. When the machine is not hitched to the tractor, it must be placed on the forward part of the sprayer's frame. Each tap permits the spraying from a single side of the head: to the right and to the left respectively.

They are **open** when the levers are set in the **vertical** position.

They are **closed** when the levers are **horizontal**.



00215

P11. CALIBRATION DISC (Patent n° 23238)


It selects the flow rates necessary to the treatment and is mounted on the distribution devices. It is made up of 2 flanges, held in position by two butterfly nuts, locking a disc with calibrated holes numbered from 1 to 15. A groove on the edge of the disc allows the exact positioning of the hole to be utilised. Its number must appear in the flange's semi-circular seat. The rotation of the disc is obtained by loosening the butterfly nuts by a few turns. After the operation is done, screw back carefully.



Any faulty sealing condition of the hydraulic circuit causes an intermittent issuing of the sprayed material. It is necessary to carefully check the efficiency of the sealers and clamps, the tightening of the ring nuts and fittings and the good working condition of the piping.

LEGEND

- 1 - UNION FLANGES
- 2 - LOCKING NUT
- 3 - ROTATING DISC WITH CALIBRATED HOLES




P19. ADDITIONAL AGITATION PUMP (For versions in which this envisaged)

Fastened on the machine right front side, it is connected to the tank (P1) through the pipes (T8 - suction) and (T11 - delivery).



THE PUMP MUST NEVER RUN DRY .

The pump is equipped with a “forced supply” coming from the main pump delivery (P4), which guarantees that the pump does NOT run dry even in the most extreme conditions (on steep slopes and with the tank almost empty).



P18. ADDITIONAL PUMP LEVER TAP (For versions in which this envisaged)


Positioned on the pipe (T8), between the main tank (P1) and the centrifugal pump (P19), it can assume the following positions:

1 - Agitation (Open)

The liquid gets out from the tank (P1) and is sucked by the pump (P19), then, through the delivery pipe (T7) it returns to the tank, so causing a further hydraulic agitation of the mixture. **The drainage is closed.**

2 - Closed

On that position, the suction of the additional pump (P19) is closed to perform maintenance on the pump.



The tap (P18) of the supplementary agitation pump must **ALWAYS** be left in “1 - AGITATION (open)” position.

The tap (P18) is to be moved to “2 - CLOSED” position **SOLELY** in the event pump (P19) is to be removed, while liquid is in the main tank.


P12. POWDER MIXER LEVER TAP (For versions in which his envisaged)

Positioned on the pipe (T6), between the main tank (P1) and the centrifugal pump (P4) (or P19 for versions in which is envisaged), it can assume the following positions:

a - Open (Mixing)

From the centrifugal pump (P4), the liquid is sent to the mixer positioned on the bottom of the cup-like filter of the main filler (BP).

c - Closed




P13. POWDER MIXER (For versions in which this envisaged)

It makes the mixing of the powdery products during the filling of the tank. It is mounted on the basket filter of the main filler (BP) and it is connected to the pump (P4) (or P19 for versions in which is envisaged) by the pipe (T6).

That device consists of a fine mesh-nylon basket, which is placed inside the tank main filler (BP). The basket is equipped with a mushroom outlet, through which the filling water coming from the pump streams out. Thanks to that system, the powder products contained inside the basket get more gradually dissolved, and the building of crumbs and thickenings can be avoided.

P26. NIPPLE FOR FLOWMETER CONNECTION

The 1”M/M nipple is placed between the delivery pipe for the sprayhead (T4) and the filter (P7), or between the pipe (T2) and the pressure control electro-valve (E5) for versions in which this envisaged, and it allows to disconnect the pipe and place a flowmeter between the pipe itself and the filter (or the pressure control electro-valve), to be used for the periodical revising tests.




P17. SPRAY-LINE RINSING TANK (For versions in which this envisaged)

The polyethylene tank, with a capacity 100 ltr. depending on the capacity of the main tank, is equipped with the filler and connection pipes to the hydraulic circuit of the sprayer.



When using the sprayer, keep the spray-line rinsing tank **ALWAYS COMPLETEY FULL** of water: in this way the machine has a better stability.



P15. UNIT-WASHING LEVER TAP (For versions in which his envisaged)

Positioned on the pipe (T1), between the tank (P1) and the pump (P4), it connects the unit-washing tank (P17) to the main pump (P4) suction.

The 3-way tap (P15) lever can be placed in the following positions:

1 - Treatment (Work)

The fluid gets out from the tank (P1) and is sucked by the pump (P4); that is the **NORMAL** operation position, which is used in order to carry out the treatment and/or to keep the mixture. **The pipe connection to the unit-washing tank is closed.**

2 - Washing process

The fluid gets out from the unit-washing tank (P17) and is sucked by the pump (P4); that is the position which is used, in order to carry out the hydraulic circuit **WASHING**.




The unit-washing circuit allows to wash the hydraulic circuit (with the exclusion of the tank), in every moment and independently on the tank load conditions, i.e., also with the mixture present inside the tank.

Close the 3-way lever tap (P2) - position "C" - by excluding the suction from the main tank.

Close the powder mixer lever tap (P12) - position "C" - to avoid the clean water returns in the main tank, with a consequent dilution of the mixture and **CLOSE COMPLETELY** the manual regulator (P5), or the electrical one (E5), during the cleaning process.

When the tap (P15) is placed to position "a - open", the clean water for the unit washing is taken from the unit-washing tank (P17).



UNIT-WASHING LEVER TAP (P15)



3-WAY LEVER TAP WITH DISCHARGE FITTING (P2)

4.4 TECHNICAL DATA

4.4.1 Sprayer dimensions and weights




On the identification plate, the full-load weight (PESO T.) of the machine is indicated, measured WITHOUT the distribution device and WITHOUT the accessories possibly installed.

			Link 50			Link 55			
			800 l.	1000 l.	1000 l. narrow	800 l.	1000 l.	1000 l. narrow	1500 l.
	LENGHT		306 cm	314 cm	306 cm	312 cm	320 cm	312 cm	377 cm
	WIDTH		109+135 cm	140+165 cm	113+139 cm	109+135 cm	140+165 cm	113+139 cm	163+210 cm
	HEIGHT		169 cm	172 cm	172 cm	169 cm	172 cm	172 cm	170 cm
	LOAD K		46 kg	44 kg	47 kg	46 kg	44 kg	47 kg	60 kg
	FAN UNIT WEIGHT	1 PUMP	221 kg			235 kg			
		2 PUMPES	226 kg			240 kg			
	TRAILED CART WEIGHT		265 kg	298 kg	281 kg	265 kg	298 kg	281 kg	460 kg
	WHEELS		7.00-12	10/80-12	10/80-12	7.00-12	10/80-12	10/80-12	10/75-15,3
	TIRES PRESSURE		2,7 atm	3,1 atm	3,1 atm	2,7 atm	3,1 atm	3,1 atm	3,1 atm
	OPTIONAL WHEELS		10/80-12	10/75-15,3	10/75-15,3	10/80-12	10/75-15,3	10/75-15,3	-
	TIRES PRESSURE		3,1 atm	3,1 atm	3,1 atm	3,1 atm	3,1 atm	3,1 atm	-



In order to calculate the weight on the hoister in operative conditions (at full load), add to the **WEIGHT OF THE FAN SERVO AMPLIFIER**, the **WEIGHT OF THE DISTRIBUTION DEVICE** which is used (see “Distribution devices – Use instructions” manual), **THE WEIGHT OF THE INSTALLED ACCESSORIES** (Par. 4.4.2), **THE 50% OF THE WEIGHT OF THE USED CARDAN SHAFT** (see the relevant specific manual) and the **LOAD “K”** on articulated joint (see Par. 4.4.1).

In order to calculate the towed weight in operative conditions (at full load), add to the weight indicated on the identification plate (**PESO T.**), the weight of the distribution device which is used (see “Distribution devices – Use instructions” manual) and the weight of the installed accessories (see Par. 4.4.2 - Weight of accessories).



4.4.2 Weight of accessories



The accessories and related data listed in this table are up to date at the time of publication of the manual. All products and accessories not included and their updated weights are available on the table (Pesi- Weights.pdf) in the ‘restricted area ‘ in the website www.cima.it, direct link (<http://drawings.cima.it/search?Query=pesi-weights.pdf>).

Description	Model	Part/Number	Weight (kg)
Oversize axle L 1000	Link 50/55 800/1000s	DIF.AS.45.06.01	2,40
Oversize axle L 1200	Link 50/55 1000 It	DIF.AS.55.10.01	2,25
	Link 55 1500 It		
Pair of wheels 10.0/75-15.3	Link 50/55 1000 It	DIFF.R.10,0/75	20,10
Pair of wheels 10.0/80.12	Link 50/55 800/1000s	DIFF.R.10/80-12	13,80

Description	Model	Part/Number	Weight (kg)
“Piemonte” sloping hubs (to be used only with oversize axle)	Link 50/55 800/1000s	DIFF.MOZZI.P.01	2,00
Electrical pressure reg.valve with remote control	Link tutti	D.V.S01	-
4 electrovalves assembly	Link: tutti	D.4E.P11	6,00
4 electrovalves assembly (E.P.A. versions)	Link: tutti	D.4E.P11E	-
Electrical pressure reg.valve + Electrical movement TC/TCS. 2M2C - 4M2C	Link 50 800/1000s	D.V.TC2.S01	-
	Link 50 1000 lt		
	Link 55 800/1000s	D.V.TC2.S02	-
	Link 55 1000 lt		
Electrical pressure reg.valve + Electrical movement TC/TCS. 2M4C - 4M4C	Link tutti	D.V.TC4.S01	-
Electrical pressure reg.valve + Electrical movement TCF. 2M4C - 4M4C	Link tutti	D.V.TCF.S01	-
Electrical pressure reg.valve + Electrical movement TCI/TCIS. 2M4C - 4M4C	Link tutti	D.V.TCI.S01	
Electrical movement 2 upper cannons TC sprayheads	Link 45/50	D.TC2.P01	2,00
	Link 55	D.TC2.P02	1,50
Electrical movement 4 upper cannons TC sprayheads	Link: tutti	D.TC4.P01	2,00
Electrical movement Upper diffusers	Link: tutti	D.TCI.P01	2,5
Free wheel (France)	Link: tutti	DIFF.R.LIB.	1,90
E.P.A. DeliveryProportional Advancement Kit	Link 50/55 800/1000s	E.08.S01	-
	Link 50/55 1000 lt	E.10.S01	-
	Link 55 1500 lt	E.15.S02	-
E.P.A. + Electrical movement TC/TCS. 2M2C - 4M2C	Link 50 800/1000s	E.08.TC2.S01	-
	Link 55 800/1000s	E.08.TC2.S02	-
	Link 50 1000 lt	E.10.TC2.S01	-
	Link 55 1000 lt	E.10.TC2.S02	-
	Link 55 1500 lt	E.15.TC2.S02	-
E.P.A. + Electrical movement TC/TCS. 2M4C - 4M4C	Link 50/55 800/1000s	E.08.TC4.S01	-
	Link 50/55 1000 lt	E.10.TC4.S01	-
	Link 55 1500 lt	E.15.TC4.S02	-

<i>Description</i>	<i>Model</i>	<i>Part/Number</i>	<i>Weight (kg)</i>
E.P.A. + Electrical movement TCF. 2M4C - 4M4C	Link 50/55 800/1000s	E.08.TCF.S01	-
	Link 50/55 1000 lt	E.10.TCF.S01	-
	Link 55 1500 lt	E.15.TCF.S02	-
E.P.A. + Electrical movement TCI/TCIS. 2M4C - 4M4C	Link 50/55 800/1000s	E.08.TCI.S01	-
	Link 50/55 1000 lt	E.10.TCI.S01	-
	Link 55 1500 lt	E.15.TCI.S02	-
Container washing device	Link: tutti	KIT.LAV.BOX	0,20
Rear lights kit	Link: tutti	KIT.LP.10.03	3,00
Hydraulic swivelling device D.175mm	Link 45/50	T.GIR.I.175P.13	-
Hydraulic swivelling device D.250mm	Link 55	T.GIR.I.250P.12	28,00
Filling pipe with foot valve and filter	Link: tutti	TUBAZ.RIEMP	2,60
Homocinetics cardan shaft	Link 45	KHP.040.120G	16,00
	Link 50/55	KHP.060.130G	24,00
Extension D.175 x 200 mm	Link 45/50	X02.186.000	2,10
Extension D.175 x 400 mm	Link 45/50	X02.187.000	3,45
Extension D.175 x 600 mm	Link 45/50	X02.188.000	4,75
Extension D.175 x 800 mm	Link 45/50	X02.189.000	6,00
Extension D.250 x 200 mm	Link 55	X21.100.020	3,40
Extension D.250 x 400 mm	Link 55	X21.100.040	5,30
Extension D.250 x 600 mm	Link 55	X21.100.060	7,15
Extension D.250 x 800 mm	Link 55	X21.100.080	9,00
Collar for D.175mm. exten- sions and elbows	Link 45/50	X05.616.000	0,40
Collar for D.250mm. exten- sions and elbows	Link 55	X05.813.000	0,95

4.4.3 Centrifugal pump CD32

Model C.I.M.A. CD32 - Grid/filter on suction - Drain plug - Filler for the connection of the filling pipe, with plug with chain.

Activated with trapezoid belt driven by the pulley mounted on the fan shaft.

Technical data printed on the body of the pump.


- Speed 4250 RPM.
- Maximum Flow rate (operating conditions) 140 litres/min.
- Pump's suction filter 7 mm
- Maximum pressure 4,5 Kg/cm²
- Power absorbed kW 2,1



The performance specified is obtained with the drive outlet (PTO) at 540 RPM. For a good result of the treatments this condition **MUST ALWAYS BE OBSERVED** during the machine's operation. Utilisation is permitted with speed rates ranging between 500 and 620 RPM.

4.4.4 Filters

- Filter (P7)..... 250 lt/min - 32 mesh
- Pump's suction filter **7 mm**
- Tank filling filters 18 mesh
- Filling pipe filter
(optional)..... 16 mesh



01676

4.4.5 Tanks

Sprayer model	Main tank volume (lt.)	Rinsing tank volume (lt.)	Main tank residual volume (lt.)
<i>Link 50-55</i>	800	80	5,2
<i>Link 50-55</i>	1000 stretto	80	5,2
<i>Link 50-55</i>	1000	100	6,5
<i>Link 55</i>	1500	100	8,4

4.4.6 Fans

	Link 50	Link 50 Super	Link 55	Link 55 Super	Link 55 Extra
Diameter (mm)	500	500	550	550	550
Speed (RPM)	3925	4210	3390	3625	3840

5.1 HITCHING TO THE TRACTOR



Check that the tractor “permissible carried weight” and “permissible trailed weight” are compatible with the sprayer weight, when this is fully loaded and complete with the equipments mounted for the treatment (see the Paragraphs “3.1” - “4.4” as well as the jointed documents).



THE TRACTOR’S POWER TAKE-OFF (PTO), UNDER ALL UTILISATION CONDITIONS, MUST PROVIDE A POWER EXCEEDING THAT ABSORBED BY THE SPRAYER.

<i>Pairing suggested for tractors of at least :</i>	<i>Link 50</i>	<i>Link 55</i>	<i>Link 55 Super</i>	<i>Link 55 Extra</i>
CV - SAE	65	70	80	90
kW	48	52	58	66



The hitching has to be carried out on a plane surface with a suitable consistency, after having checked that all the people not charged with the operation moved away, as well as the children and the animals possibly present.



On-road use is permitted only in accordance with the rules in force in the country of use, without having loaded chemicals in the tank.


EXECUTION::

- Loosen the chains of the lifter arms.
- Start the tractor and take the lifter’s arms to the level of the machine’s pins.
- Stop the tractor and remove the key from the control panel.**

- Insert the toggle joints on the machine’s pegs, locking them with the clip pins.
- Hook the 3rd-point rod from the tractor to the machine and securing it with the peg and the clip pin.
- Screw the rod to set it into tension.
- Start the tractor and hoist the sprayer until the 2 PTO are the same height.

- Stop the tractor, remove the key from the control panel and make sure that no one approaches the hydraulic controls of the lifter.**
NEVER OPERATE OR STAND BENEATH THE MACHINE OR IN THE AREA THAT COULD BE INVOLVED IN ITS SUDDEN LOWERING.

- By acting on the 3rd-point rod, vertically align the sprayer. N.B.: block the 3rd-point rod with the specific lock ring..
- Block the coupling by tightening the chains of the hoister arms.





When the operation is completed the 2 drive outlets (PTO) must be positioned on the same axis, both in vertical and horizontal direction.

5.2 MOUNTING OF THE TRANSMISSION SHAFT



The mounting, disassembling or possible other interventions on the transmission shaft must be carried out with the engine switched off and with the starter key removed from the tractor's control panel.


Use transmission shafts with CE certification.



Observe the regulations contained in the use and maintenance booklet provided by the shaft manufacturer.



The cardan transmission shaft must work with the 2 COAXIAL drive outlets (PTO) or, should this not be possible, with the PARALLEL axles. In this case the angle of the joint MUST NOT EXCEED 15°..



DEFINITION OF THE TRANSMISSION SHAFT LENGTH


Set the 2 drive outlets (PTO) perfectly on the same axis and measure the distance "D" between their grooves. Length "L" of the cardan transmission shaft (refer to the picture) to be deployed, measured between the 2 stopping pawls and with joint closed, must be 40÷50 mm lesser than distance "D".



Using the cardan shaft too much short can cause the breach of it, with serious damages to the sprayer and/or to the tractor, and dangerous for the persons.



Using the cardan shaft too much long cause a push on the two PTO, that it can cause huge mechanical damages both to the tractor and to the sprayer.




5.3 INSTALLATION OF REMOTE CONTROLS

5.3.1 Electrical control panel - E10

- 1 - Fix the fastening bracket near to the driver (if not already available on the tractor).
- 2 - Insert the bayonet support of the control panel in the securing clamp and position it so that the controls are fully visible and accessible during use.

3. Connect the distribution piping (T5) to the hydraulic circuit of the distribution device (head) mounted on the machine (follow the instructions of the specific "use and maintenance" booklet which is supplied with it).
4. Connect the feeding pipe (T4) with the electrical distributor (E9).
5. Connect the power supply cable "W1" plugging it in the socket of the tractor.



Position the electrical cables W1 and W2 in such a way as to avoid risking their being wrenched off during treatments. If necessary, use some securing clamps. A sudden interruption of power will lock the 2 electrovalves of the electrovalves assembly "E9". Should this fault take place when they are in the open position, it is necessary to:


- Stop the tractor and remove the key from the control panel.
- Position the cock (P2) to "B".
- Restore the electric current.

IN CASE OF A PIPE BURST:

- 1 - Stop the tractor and remove the key from the control panel.
- 2 - Close the electrovalves assembly (E9), the switches on the control panel (E10) must be on OFF.
- 3 - Close the pressure regulator (P5) turning clockwise the pressure regulation knob or keep the joystick (E10) in position "+" for at least 15 seconds on the electrical control box.
- 4 - Replace the broken pipe (for the elimination of these parts, please follow the current regulations..

5.3.2 Manual 2-tap distributor - P9 (for the versions where foreseen)

- 1 - Mount the fastening bracket on the tractor within the driver's reach (if this is not already present on the tractor).
- 2 - Insert the distributor's bayonet support in the securing bracket and position it so that the controls are fully visible and accessible during use.
- 3 - Connect the feeding pipe (T4)
- 4 - Connect the distribution piping T5 to the hydraulic circuit of the distribution device (head) mounted on the machine (follow the instructions of the specific "use and maintenance" book-let which is supplied with it).



Position the distribution piping T5 and feed piping T4 so as to avoid the risk of suffering damage or breakage during spraying. It may be needed to shorten the pipes; IT MAY BE NEEDED TO SHORTEN THE PIPES.

IN CASE OF A PIPE BURST:

- 1 - Stop the tractor and remove the key from the control panel.
- 2 - Close the 2 taps of distributor (P9).
- 3 - Move the 3-way cock (P2) lever to position "3", filling.
- 4 - Close the cock with pressure regulating handgrip (P5) (turn it clockwise).
- 5 - Repair or replace the broken pipes (for the elimination of these parts, please follow the current regulations).


5.3.3 E.P.A. Control Unit



Act in a similar way as indicated for installing the electric control panel (E10) (see Paragraph 5.3.1.)



Position the electric cables in such a way to prevent them from getting torn during the treatment..







Every distribution device is supplied with its own **USE AND MAINTENANCE** booklet that is, or will have to be, attached to this publication and will constitute one of its integral parts.



The manual “Distribution devices - Operation and maintenance instructions” illustrates the wide range of distribution devices (sprayheads) that can be used with each sprayer and also contains assembly instructions; if necessary, a specific assembly diagram is provided with the “Spare parts catalogue” of each sprayhead.

All usable distribution devices are easy to orient and adjust to guarantee perfect coverage, in compliance with the actual needs of the area being treated.

Simple sprayheads



Combined sprayheads



7 ACCESSORIES 7

7.1 FILLING PIPE

The pipe is provided with a coupling elbow fitting and with a **bottom-drawing valve**. This is used for the filling of the tank.


It must be connected to the pump suction (P4) instead of the chain-held stopper.



The assembly has **ALWAYS** to be carried out with the lever of the cock (P2) positioned on **“B”**.



USE ONLY IF CONCURRED FROM THE LAWS OF THE COUNTRY WHERE THE SPRAYER IS USED. Before utilisation, check the operation and proper sealing of the bottom-drawing valve by pouring water in the piping.




7.2 HYDRAULIC SWIVELLING DEVICE

It is an accessory for modifying the direction of the spraying. It is used only with some types of distribution devices, spraying one side only.




All indications and instructions are provided in the **“Distribution heads - Operation and maintenance instruction”** booklet of the distribution devices with which it can be used.



7.3 ROTARY BLADES' HYDRAULIC MIXER (PATENT N° 1295858)

(For versions in which his envisaged)


The mixer consists of a header, to which some oriented feed openings, equipped with mixing paddles, are applied. The mixer is mounted inside the tank through two hollow supports, a front and a rear one, which are equipped with bushes allowing it to rotate. The water coming from the additional pump is conveyed, through the supports, to the header and from that one to the oriented feed openings. The water streaming out causes, as a reaction, the mixer rotary movement, so adding to the mixture hydraulic agitation, the mechanical agitation caused by the paddles' movement.



7.5 REAR LIGHTS KIT

(For versions in which his envisaged)


The wired backlights kit is constituted by two complete back lights (parking lights, stop lights and direction indicators) and with hangers for the anchorage to the frame of the sprayer.



7.6 EPRESSURE ELETTROREGOLATOR

(For versions in which his envisaged)

The pressure electroregulator can be installed in substitution of the manual regulator. The joystick for the electroregulator control is in the electric switchboard (E10).



7.7 E.P.A. KIT - DELIVERY PROPORTIONAL ADVANCEMENT

(For versions in which his envisaged)


The computerized E.P.A. system executes the monitoring of the distribution parameters for the active automatic control of the distribution proportional to the feed.

Through the constant takeover of the feed speed and the range of the product it is able to regulate the pressure continuously to keep the quantity of distributed product constant in relation to the treated surface.

The Kit is available in the “Teejet® 844AB” version, constituted from:

1. Magnetic induction proximity sensor (speed survey);
2. Pressure transducer (pressure survey);
3. Motorized electric valve (pressure regulation);
4. Computerized unit;
5. Dedicated printer (on demand).

For further information refer to the specific handbook.



FILLING MUST BE CARRIED OUT WITH THE MACHINE ON A FLAT SURFACE. ON THE SITE, BEFORE THE OPERATION, THE DOSES OR THE MIXTURES TO BE POURED INTO THE TANK MUST BE PREDISPOSED.





IT IS NECESSARY TO ALWAYS MAKE USE OF PERSONAL PROTECTION.


8.1 FOREWORD - USE OF THE FAN DISENGAGEMENT

(For versions in which his envisaged)

8.1.a Disengagement of the fan

EXECUTION:



1.   Stop the tractor, remove the key from the control panel and check that the fan has stopped.
2. Unscrew the nuts that fix the removable protection cover and remove it to enter the release tunnel.



3. Fully press the spring push button and pull the front element until it springs out. The body disengaged from the retaining joint must turn freely: the pump will operate and the fan will thus be excluded.
4. Reposition the removable protection cover and fasten the locking nuts properly.
5. Start the tractor and carry out the filling operation.

8.1.b Fan engagement to perform the treatment

EXECUTION:

1. Disengage the power take off (PTO)
2.   **Stop the tractor, remove the key from the control panel and check that the fan is stopped.**
3. Unscrew the nuts that fix the protection mobile cover and remove it to enter the release.
4. Fully press the spring push button, push the front body forward, if necessary, turning it to the right or left, until the frontal teeth of the joint engage the corresponding teeth of the pulley; at the same time, the spring push button must return to the outward position. This way, the body is again integrated with the pulley, thus transmitting the movement to the fan.
5. Reposition the mobile protection cover and suitably tighten the securing nuts.
6. Start the tractor.

8.2 FILLING THROUGH POURING FROM THE TOP



For this type of filling, use the supplementary filler (BS) located in the upper side of the tank, towards the rear of the sprayer.

THE INLET OF THE FILLER PIPING MUST NEVER COME INTO CONTACT WITH THE ANTI-PARASITIC MIXTURE: IT MUST ALWAYS BE KEPT AT A SAFE HEIGHT ABOVE THE TANK FILLER AND MUST BE EQUIPPED WITH A NON-RETURN VALVE.



THE PUMP MUST NEVER RUN DRY

EXECUTION:

1. Disengage the fan (for the version where foreseen): see point 8.1.a.
2. Verify that the lever of the 3-way cock (P2) it's in the position "A".
3. For the version where foreseen: verify that the spray-line rinsing cock (P15) is on "c" position.
4. Completely open the pressure regulator (P5), by rotating counterclockwise the handle or by setting the pressure at zero (keep the joystick on "-" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
5. For the versions with the additional agitation pump: verify that the cock (P18) lever of the additional agitation pump (P19) on "1";
6. Close the cocks of the 2-way distributor:
 - a. if electric (E9), position to "OFF" the quick-break switches on the control panel (E10) or on the control unit for E.P.A. versions;
 - b. if manual (P9), the levers are to be lowered (horizontally positioned);
7. Verify that the lever of the cock (P12) it's in the position "A".
8. Pour some water into the tank, for about 1/3 of its capacity, by acting from the secondary filler (BS).
9. Start the tractor and engage the PTO; **then bring it up to a 500 r.p.m. rate.**





Use ONLY the PTO at 540 rpm. Engage the PTO with the engine of the tractor at low speed and with maximum modularity, obtaining soft and progressive graft and avoiding abrupt starts of the cardan shaft.

10a. WHEN NOT USING THE MIXER (WITH MEDICINE MIXTURES OR LIQUID PRODUCTS)

- 10a.1. Pour the mixture of water and plant protection product previously prepared (or the liquid product) (and the possible washing water for the medicine packs and for the instruments used for preparing the mixture) into the main filler (BP).

- 10a2. Close the main filler (BP) of the tank.
- 10a3. Complete the filling with water through the secondary filler (BS), **by keeping PTO in running.**
- 10a4. Close the cover of the secondary filler (BS).
- 10b. **WITH POWDER PRODUCTS, WHEN USING THE MIXER (IF FORESEEN)**
- 10b1. Pour the powder medicine dose into the cup-like filter of the main filler (BP).
- 10b2. Close the main filler (BP) of the tank.
- 10b3. Open the cock (P12), by positioning the lever on **"B"**.
- 10b4. Complete the filling with water through the secondary filler (BS), by keeping PTO in running.
- 10b5. Close the cock (P12), by positioning the lever on **"A"**.
- 11. Move to the place to be treated, by keeping the mixture agitation at a 500 r.p.m. PTO turning rate along the whole way.

FILLING DIRECTLY IN THE TREATMENT AREA:

- 12. Disengage the power take off (PTO)
- 13.   **Stop the tractor and remove the key from the control panel.**
- 14. Make sure that the fan is still. Engage the impeller to the multiplier, as indicated at Paragraph 8.1.b.



Tighten the protection-securing nuts properly.

- 15. Start the tractor.
- 16. Engage the Power Take Off and set it up to a running rate of at least 500 r.p.m., in order to carry out a further agitation.



Use ONLY the PTO at 540 rpm. Engage the PTO with the engine of the tractor at low speed and with maximum modularity, obtaining soft and progressive graft and avoiding abrupt starts of the cardan shaft.



- 17. Regulate the operating pressure, by acting on the pressure regulator (P5) (or electric E5, for versions where provided) with the distributor, hand (P9) or electric (E9), open (DISTRIBUTION).
- 18. CARRY OUT THE TREATMENT (See the Paragraph 10.3).

8.3 FILLING WITH THE SPECIFIC PIPE

(OPTIONAL ON DEMAND)



USE ONLY IF CONCURRED FROM THE LAWS OF THE COUNTRY WHERE THE SPRAYER IS USED. Before utilisation, check the operation and proper sealing of the bottomdrawing valve by pouring water in the piping.



THE PUMP MUST NEVER RUN DRY.

EXECUTION:

- 1. Disengage the fan, see point 8.1.a.
- 2. For the versions on which it is foreseen: check that the cock (P18) is open: (lever positioned on "1").
- 3. For the version where foreseen: verify that the spray-line rinsing cock (P15) is on "c" position.
- 4. Verify that the outlet on the faucet (P2) is closed by the special plug with chain.
- 5. Position the lever of the 3-way cock (P2) to "B".
- 6. Close the cocks of the 2-way distributor:

- a. if electric (E9), position to **"OFF"** the quick-break switches on the electrical control panel (E10) or on the E.P.A. control unit.
- b. if manual (P9), the levers are to be lowered (horizontally positioned);
7. Verify that the lever of the cock (P12) it's in the position **"A"**.
8. Completely close the pressure regulator, by turning clockwise th handle of the manual regulator (P5) or by turning the pressure up (keeping the joystick on "+" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
9. Connect the filling pipe to the pump (P4).
10. Immerse the filter with the bottom-drawing valve in the water to be loaded.



The filter must always be below the level of the water to be loaded. The piping must never be above the pump's suction point and must never be excessively bent in the vertical direction.

11. Position the lever of the 3-way cock (P2) to **"A"**.
 12. Completely open the pressure regulator (P5), by rotating counterclockwise the handle of the hand regulator (P5) or by setting the pressure at zero (keep the joystick on "-" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
 13. Through the secondary filler (BS), pour into the tank about 15/20 litres of water: that quantity must be enough TO FILL the pipe and TO PRIME the pump (P4).
 14. Start the tractor and engage the PTO; then bring it up to a 500 r.p.m. rotation rate.
 15. When the pump will have started the recycling of the poured water, close the cock (P3), by positioning the lever to **"B"**, in order to start the filling through the return pipe (T3).
- 16a. WITH MEDICINE MIXTURES OR LIQUID PRODUCTS (WHEN NOT USING THE MIXER)**
- 16a1. Pour the mixture of water and plant protection product previously prepared (or liquid product) foreseen for every loading (and the possible washing water for the medicine packs and for the instruments used for preparing the mixture) into the main filler (BP).
 - 16a2. Close the main filler (BP) of the tank and wait until the filling is completed.
- 16b. WITH POWDER PRODUCTS, WHEN USING THE MIXER (IF FORESEEN)**
- 16b1. Pour the dose of plant protection product in powder into the cup-like filter of the main filler (BP).
 - 16b2. Close the main filler (BP) of the tank.
 - 16b3. Open the cock (P12) by positioning the lever on **"B"** (MIXING) and wait until the filling is completed.
 - 16b4. Close the cock (P12) by positioning the lever on **"A"** (WORK).
18. Completely close the pressure regulator (P5), by turning clockwise the handle of the manual regulator (P5) or by setting the pressure at zero (keep the joystick on "+" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
 19. Remove the filling pipes from the pump (P4) and position again the closing plug.
 20. Completely open the pressure regulator (P5), by rotating counterclockwise the handle of the hand regulator (P5) or by setting the pressure at zero (keep the joystick on "-" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
 21. Position the lever of the 3-way cock (P3) to **"A"**.
 22. Engage the Power Takeoff and move to the treatment place, keeping the Power Takeoff running rate at least 500 RPM during all the operations of the treatment.

IN THE AREA OF THE TREATMENT:

23. Disengage the power take off (PTO).



24. **Stop the tractor and remove the key from the control panel.**

25. Make sure that the fan is stopped. Hook the fan to the servo amplifier as indicated at point 8.1, then mount back the release mobile protection cover.



Properly tighten the nuts securing the mobile protection cover.

26. Start the tractor.

27. Engage the Power Takeoff and set it up to a running rate of at least 500 r.p.m., in order to carry out a further agitation.

28. Regulate the operating pressure, by acting on the pressure regulator hand regulator (P5) (or electric E5, for versions where provided) with the distributor, electric (E9) or hand (P9), open (DISTRIBUTION).

29. CARRY OUT THE TREATMENT (See the Paragraph 10.3).

* per versioni dove previsto

A
Posizione Lavoro
Working position
Position de travail
Posición de trabajo

B
Miscelazione
Mixing
Mélange
Mezclas

C
Chiusura
Close
Fermé
Cerrado

05100

P12

A

C

B

01110

P18*

a

c

00105

P2

A

B

C

01111

P15*

a

c

01018

LAVAGGIO	CLEANING	NETTOYAGE	LIMPIEZA
EROGAZIONE ACQUA DI LAVAGGIO CLEAN WATER FLOW FOR CLEANING FLUX D'EAU DE NETTOYAGE FLUJO DE AGUA PARA LAVADO		ARRESTO FLUSSO SERBATOIO PRINCIPALE FLOW STOP FROM MAIN TANK ARRET FLUX DU RESERVOIR PRINCIPAL PARADA FLUJO DEL TANQUE PRINCIPAL	

P9*

00093

E10

00094

P5

00240

A	POSIZIONE LAVORO WORK POSITION POSITION DU TRAVAIL POSICION DE TRABAJO
B	COLLEGAMENTO/SCOLLEGAMENTO TUBO REMPL. CONNECTION/DISCONNECTION TUBAU DE REMPL. CONEXION/DESCONEXION TUBO DE CARGA
C	SVIUTAMENTO SERBAT./POMPA TANK & PUMP DRAINING VIDAGE CUVE ET POMPE DRENAJE DE TANQUE Y BOMBA

elmu 95080

54

Rev.07 - Jan. 2017

The **hydraulic** and the **pneumatic** circuits mounted inside the tank, allow to realize a **double agitation system**: with the pump water and with the fan air, **at the same time**. The pneumatic circuit can be excluded, when the products used have a quite strong foaming effect, by closing the pneumatic agitator cock. When that cock is opened again, check that some air outlet holes aren't obstructed.



It is advised however to also use always the pneumatic agitator, adding to the mixture, if necessary, a antifoam product.

This operation is of main importance, in order to get a uniform distribution of the active principle on the whole vegetative surface to be treated. Should the activity need to be interrupted during a treatment with the sprayer, **keep the agitator activated until the treatment is resumed**.



Before starting the treatment, or return to work after a break, it is essential to agitate the mixture in the tank, re-circulating it completely for as long as it takes to make it homogeneous.



The agitation can be carried out with the manual pressure regulator (P5) or electric (E5), in any position.

The tap of the pneumatic regulator has to be open.

THE MIXTURE AGITATION HAS TO BE CARRIED OUT WITH THE POWER TAKEOFF RUNNING AT A RATE OF AT LEAST 500 RPM.



Before using the atomizer fill the circuit-washer tank (if provided) and the hand-washer tank with clean water.

10.1 PRELIMINARY OPERATIONS TO TREATMENT

- **The operator must:**
 - a. Ascertain that the condition of the crops, the progress of the disease or the need for its prevention actually justify the treatment to be applied;
 - b. Be aware of the meteorological conditions forecast for all the time necessary for carrying out the treatment;
 - c. If possible, avoid carrying out the spraying in strong wind conditions or when one detects that the sprayed mixture disperses away from the target crop (drifting). It is advisable to suspend the treatment when the wind speed exceeds 3 m/s (10 km/hour). Should it be imperative to operate anyway, the following suggestions are made:
 - reduce the distance of the target from the spraying points, even if detrimental to the quality of the spraying
 - increase the dimension of the droplets, suitably adjusting the machine.

- d. Check that multiple-product mixtures be physically, chemically and biologically compatible amongst themselves; if need be, obtain the necessary information from the products' sales representative.
- e. Carefully calculate the exact quantity of the product necessary for the treatment and establish the volume of water to be used for the intervention.
- f. Check that the product is available in a quantity sufficient to complete the intervention.
- g. Read the product's utilisation instructions carefully, in order to ascertain the usage conditions, the correct dosage and the expiration dates.
- h. Make sure of the parameters necessary to the adjustments of the machine and determine the exact dose of product to be applied to every loading. **Follow the instructions of the publication titled "The low volume - Instructions for sprayers adjustment" as well as those contained in the use and maintenance book-let of the distribution device.**

10.2 PREPARATORY OPERATIONS TO TREATMENT



THE FILLING MUST BE CARRIED OUT WITH THE MACHINE ON A FLAT SURFACE. BEFORE THE OPERATION, IN THE ALLOCATED AREA, THE DOSES OR MIXTURES TO BE POURED IN THE TANK MUST BE MADE READY.

Before starting the filling cycle, check:

- THE TIGHTENING OF THE RUDDER, AXLE, HUBS AND WHEELS FIXING BOLTS SCREWS;
- TENSION OF MAIN TANK FIXING BELTS;
- TYRES PRESSURE;
- THE LEVEL OF THE OIL OF THE FAN SHAFT SUPPORT;
- THE CLEANING OF THE FILTER CARTRIDGE (P7);
- THE EFFICIENCY OF THE DISTRIBUTION DEVICE (HEAD).
- THE CONDITIONS OF THE TANK LEVEL INDICATOR.

• **The operator must:**


- a. Wear adequate protective clothing and accessories such as overalls, waterproof suits, gloves, glasses and masks to shield him from contamination by inhalation or contact with the products handled.



- **Anti-dust masks don't offer any protection against toxic vapours.**
- **Avoid wearing loose clothes that might entangle with moving parts.**

- b. With the parameters defined during the preliminary operations, carry out the adjustments of the sprayer.
- c. Prepare the mixtures in a well ventilated area. When in the open, the presence of wind increases the danger of contamination.
- d. Precisely weigh the previously calculated doses of products to be mixed at every filling operation.
- e. Avoid handling products close to open flames, embers, incandescent bodies or in the presence of flammable substances.
- f. In order to obtain the correct volume dosage of agro-chemicals and fertiliser mixtures, the fertiliser must be first diluted.

- g. Wash and rinse the just emptied product containers with clean water – collect the washing water and pour it in the tank before carrying out the filling – place the empty packaging in the specific container or in the collection area.
- h. Wash the equipment and tools utilised in the preparation and place them in the chemical products storage area.
- i. **Always** leave the area assigned to the loading and preparation of the mixtures in such condition as to avoid **any** possibility of contamination to persons or animals or of pollution to the environment.
- l. With indelible pen put the name of the product used for the treatment (or of several names) on the decal 10x10 cm and put it on the provided support on the machine.



- m. If necessary, mark the field or the area of machine passes in order to provide a guide for the treatment and avoid missing or double-treating coverage areas.



- AT THE END OF THE OPERATIONS NECESSARY FOR CARRYING OUT THE INTERVENTION, THE LOCATION-STORAGE AREAS MUST BE LEFT IN THE CONDITION REQUIRED FOR THE CARRYING OUT OF THEIR PREVENTION AND PROTECTION FUNCTIONS.
- BEFORE STARTING THE GRAPE HARVESTER, KEEP AWAY PERSONS OR ANIMALS AND NEVER LEAVE IT UNATTENDED DURING THE PREPARATION OPERATION.

10.3 THE TREATMENT



IT IS ADVISABLE TO BEGIN TREATMENT AT THE HEADLANDS.



WHEN THE TREATMENT IS OVER, OR IF THE SAME HAS TO BE TEMPORARILY INTERRUPTED, ALWAYS LET THE FAN STILL OPERATE FOR APPROXIMATELY 10 SEC AFTER CUTTING-OUT THE POWER SUPPLY (either electrical distributor E9 or manual distributor P9), IN ORDER TO FULLY ELIMINATE THE PRODUCT MIXTURE FROM THE DISTRIBUTING DEVICES, SO PREVENTING ANY POSSIBLE ANOMALOUS DRIPPING FROM TAKING PLACE.

- **The operator must:**

- a. **Shake the mixture** in the tank before starting the treatment, re-circulating it completely for as long as it takes to make it homogeneous.
- b. **Check** the orientation of the distributors (hands and/or cannons) of the distribution device (sprayhead) in relation to the dimensions, the shape and the thickness of the vegetation to be treated.
- c. Continue to shake the mixture until the treatment is resumed should the intervention momentarily be interrupted. If the utilisation is to be deferred, check that the filter cartridge is clean before resuming and **agitate the mixture** that has remained in the tank.
- d. Ensure that the hand wash supplementary tank is filled with clean water after each filling operation.
- e. Make use of individual protections identical to those envisaged for the preparation of mixtures if the tractor is not equipped with a pressurised cabin with aeration filters.
- f. Wash immediately all the elements that might have become contaminated during the treatment, promptly remove the polluted garments and **interrupt the work if these cannot be immediately replaced**.
- g. Keep to the preliminary operations already indicated (10.1.c), in case of wind conditions prevailing.
- h. During the breaks, stop the engine, remove the key from the grape harvester's control panel.
- i. Pay particular attention to the treatment when close to boundaries and in proximity of dwellings, waterways, roads or public-usage paths.

10.4 PROCEDURE TO WASH THE HYDRAULIC CIRCUIT

(sprayhead-pump)



Every time it is necessary to suspend the treatment, it is possible to carry out the hydraulic circuit washing process, independently on the loading conditions, i.e., also when the tank is still containing some product mixture, so avoiding any possible clogging and assuring the perfect efficiency of the machine when the treatment is carried on again.

In case of prolonged idle periods, it is recommended to keep the mixture agitated (see Chapter 9).

- a. Close the pressure regulator completely, by rotating the hand regulator (P5) handle clockwise or by turning the pressure up (keep the joystick on "+" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
- b. Close the tap (P12) - lever on "C" position, so the water of the spray-line rinsing circuit can not back into the main tank by varying the concentration of the mixture used.
- c. Close the tap (P2) - lever on "B" position.
- d. Open the cock (P15), by setting it to position "a"; in that way the clean water contained inside the unit-washing tank is sucked by the pump (P4) and gets into the hydraulic circuit.
- e. Engage the PTO and take it to the correct distribution condition (540 rev/min - see Paragraph 4.4.3).




CAUTION: THE PUMP MUST NEVER RUN DRY.

- f. Open the electrovalves (E9) by taking the switches of the control electric switchboard (E10) on ON (or lifting the lever of manual distributor switches P9); make the atomizer work spraying on the piece of ground not treated yet for a time sufficient to verify the leakage of fresh water from the distribution head. Close the electrovalves (E9) by taking the switches of the control electric switchboard (E10) on OFF (or lowering the lever of manual distributor switches P9).

That easy procedure allows to eliminate every fuel mixture residual from all the hydraulic circuit components, so assuring in first place the accurate cleaning and the consequent efficiency of the calibrated holes of the rotary disc regulators.

- g. Disengage the PTO.
- h. Close the cock (P15) by taking it to the 1-WORK position.
- i. Position the lever of the 3-way cock (P2) it's in the position "A - Working position".



10.5 END OF TREATMENT - STORAGE

10.5.1 Daily

The operator must:

if the machine s equipped with the spray-line rinsing tank:

- a. Carry out the hydraulic circuit washing process (see paragraph 10.4) spraying on the piece of ground treated yet. Attention: to make to spray the sprayer for around 5 sec..
- b. Wash the inside of the tank:
 1. Disengage the fan (for the version where foreseen): see point 8.1.a.
 2. Close the taps of the 2-way distributor:
 - if electrical, position the latch switches (E10).on "OFF"
 - if manual (P9), set the levers in the horizontal position;
 3. Close the pressure regulator completely, by rotating the hand regulator (P5) handle clockwise or by turning the pressure up (keep the joystick on "+" for about 15 seconds) for the versions with electrical pressure regulator (E5).
 4. Put the cock (P2), in to position "B" (washing)
 5. Put the cock (P15), in to position "2" (washing)
 6. Engage the drive outlet (PTO) and take it to a speed of 540 RPM.



Use ONLY the PTO at 540 rpm. Engage the PTO with the engine of the tractor at low speed and with maximum modularity, obtaining soft and progressive graft and avoiding abrupt starts of the cardan shaft.

7. Put the cock (P12), in to position "B" (mixing).
8. Rinse the tank until the water in the spray-line rinsing tank is totally run out.
9. Disengage the drive outlet (PTO).
10. Put the cock (P12), in to position "A" (work).
11. Put the cock (P15), in to position "c" (closed-work).
- 12a. Discharge the rinsing water in area with a drain basin and arrange the waste following the country rules.

Or

- 12b. Spraying the rinsing water in the previously treated area. Discharge the remaining water of the tank and pipes, gathering it in a proper container to waste it following the country rules or use it again, putting in the tank, for a next treatment if thi will be suitable with the product tu use.

if the machine HAS NOT a spray-line rinsing tank:

- a. Put about 15 lt.of clean water in the tank and spraying it in the already treated area.
- b. Wash the tank:
 1. Put in the tank a quantity of clean water equal to almost 10% of tank capacity, with the agitator while running.
 - 2a. Discharge the rinsing water in a proper area provided with a drain basin for the collection and take care of waste according to the country rules.

Or

- 2b. Spraying the rinsing water in the already treated area. Then, discharge the remaining water of the tank and pipes gathering it in a proper container to waste it following the rules or use it

again, putting it again in the tank, for a next treatment, if this will be suitable with the product to use.

- c. Wash the machine externally:



To wash it externally DO NOT USE high pressure washer (MAX 5 bar).

When each treatment has finished, it must wash the sprayer outside, in a proper area provided with a drain basin for collection and subsequently treatment of rinsing water.

These area are forbidden to unauthorized personnel, children and pets.

To outside sprayer rinsing, it is possible to use proper cleaning products and biodegradable to make the operation easier.

When the rinsing is finished, switch on the fan for few second (about 10) to remove residual water on carter and pipes which lead the flow to the sprayhead.

- d. Check the efficiency of the distribution device (head) and the cleaning of the pulverising points (diffusers), possibly replacing them if found to be damaged.
- e. Clean out the filter cartridge.
- f. Keep the machine in a ventilated place, sheltered from rain or sun: sunrays are the worst enemies of plastic and rubber parts.



The machine must be stored in a secure or closed place, so as to prevent access to unauthorized personnel.

10.5.2 End of seasonal cycle

• **The operator must:**

- a. Take the utmost care in carrying out the operations envisaged at the end of the daily treatments: the cleaning of the hydraulic circuit must be done at least twice. Check that no product residues are left in any part of the circuit.
- b. Execute the necessary maintenance and lubrication operations (see Paragraph 13.8), then let the atomizer operate for some minutes.



THE PUMP HAS NEVER RUN DRY.

- c. Completely drain the hydraulic circuit, paying a special attention to the centrifugal pump; in order to completely drain the pump, remove the draining plug, which is mounted on the pump itself.




Avoid using anti-freeze solutions.

- d. Check the proper operation of all parts and of the machine structure. In case of faults being detected, request the intervention of one of our service points.

- e. Keep the machine on a plane surface with a suitable consistency, in a well ventilated place, sheltered from rain, icing and direct sun rays.



The machine must be stored in a secure or closed place, so as to prevent access to unauthorized personnel.so.



11 TANK AND HYDRAULIC CIRCUIT DRAINING 11




- Stop the tractor and remove the key from the control panel.
- Wear suitable protective clothing and accessories in order to avoid contamination by contact or inhalation of the mixture.
- Carry out the discharging in a suitable and properly geared area for the collection of the washing liquid.

This operation has to be carried out with the lever tap (P2):

1. Position the lever of the 3-way cock (P2) to “A - WORK POSITION” (draining closed).
2. Unscrew the drainage plug.
3. Turn the lever to position “C - DRAINING” (draining open).
4. When the draining is completed, position again the lever tap (P2) to “A” (agitation), and screw again the chain plug.

For the version where foreseen:

1. To make the discharge of the circuit of additional agitation pump (P19) close the cock (P18), position “2”.
2. Unscrew and remove the drain plug with chain from pump (P19) to drain the pipes.
3. Complete emptying, replace drain plug and return the lever cock (P18) to “1”.





THE FOLLOWING ACTIONS ARE NOT ALLOWED:

- Transporting or lifting the sprayer with residual quantities of mixture in the tank for purposes differing from its destined usage.
- The transporting of people, animals or things.
- The trailing of vehicles or equipment.



Road transport must take place in the complete observance of road regulations in force in the Country where the machine is used. The operator is responsible for possible defaults due to the non observance of said regulations.

12.1 LIFTING AND TRANSPORT OF THE SPRAYER




Before carrying out any operation it is essential to verify that no mixture residues are left in the tank.



In order to transport the sprayer, the trailed cart (2) must be detached from the servo amplifier-fan unit (1).



CAUTION: should the sprayer be equipped with a distribution device (head) of the “combined with supporting frame” type, it could be necessary to remove the same one (see the “Distribution devices – Instructions for use and maintenance” manual).




12.1.1 Trailed cart disengagement



The disengagement and the subsequent re-attachment of the trailed cart must be carried out on a horizontal plane, after having cleared the same from any person not concerned by the operation, as well as from any children and animals possibly present.


- 1 - Stop the tractor, actuate the parking brake and remove the key from the control panel.
- 2 - Release the locking lever (3) and lower the bearing foot (2) up to the ground.
- 3 - Tighten the lever (3), in order to lock the bearing foot (2).
- 4 - By acting on the mechanical power lift of the tractor, lift it up to discharge the drawbar eye (1).




- 5 - Disconnect the pipes (5), (6) and (7) which connect the servo amplifier-fan unit to the rear trailed cart and to the pipe (4) for the pneumatic agitation..




The length and the position of the pipes detachment/re-attachment points prevent the possibility that the same ones can be connected in a wrong way; anyway, provide to opportunely countermark the same ones in order to prevent any possible assembly errors.




- 6 - Remove the clip pin (8) from the end of the pin (9) which fastens the drawbar eye (1) to the joint of the servo amplifier-fan unit.
- 7 - Remove the pin (9) fastening the drawbar eye.
- 8 - By acting on the mechanical power lift, lift the delivery unit so disengaging the drawbar eye (1).
- 9 - Insert again the pin (9) into the bracket of the joint, and lock it there by means of the clip pin (8).



- 10- Lift the servo amplifier-fan unit as far as necessary in order to make it possible to position the bearing feet (10) on parking position..



- 11- Place the servo amplifier-fan unit on the ground and disconnect it from the mechanical power lift of the tractor.




12- Check that the lifting devices (bands, ropes, etc.) are adequate for the weight to be lifted (machine, distribution devices, accessories)

12.1.2 Lifting of the fan servo amplifier assembly

1. Hook the fan servo amplifier assembly through the specific support point indicated by the specific decal on the frame, checking all the parts involved in the operation.
2. Lift the servo amplifier assembly, verifying that it is properly balanced.
3. Position the servo amplifier assembly on the transporting vehicle in perfectly stable conditions.
4. During transport the servo amplifier assembly must be immobilised and fastened to the carrier by way of suitable strapping.

12.1.3 Lifting of the trailed cart

1. Hook the trailed cart through the specific support point indicated by the specific decal on the frame, checking all the parts involved in the operation.
2. Lift the trailed cart , verifying that it is properly balanced.
3. Position the trailed cart on the transporting vehicle in perfectly stable conditions.
4. During transport the trailed cart must be immobilised and fastened to the carrier by way of suitable strapping.



01720

13 MAINTENANCE OPERATIONS 13



ALL OPERATIONS MUST BE CARRIED OUT WITH THE ENGINE SWITCHED OFF AND WITH THE IGNITION KEY REMOVED FROM THE CONTROL PANEL.




The machine has to be periodically revised according to the country rules. The inspections and the release of the certificate have to be made by special provided structure of the country where the machine is used.

13.1 LUBRICATION

MAINTENANCE POINT	ACTION	COMSUMPTION MATERIAL	PERIODICITY
FAN SHAFT BEARINGS SUPPORT	Check oil level	Oil SAE 90	8 hours
FAN BELT TENSIONER SUPPORT	Greasing	Grease type EP Class NLGI 2	1 year
FREE WHEEL	Greasing	Grease type EP Class NLGI 2	1 year
FRAME ARTICULATED JOINT	Greasing	Grease type EP Class NLGI 2	200 ours
DRAWBAR EYE	Greasing	Grease type EP Class NLGI 2	200 year
WHEEL HUBS	Greasing	Grease type EP Class NLGI 2	200 year
SUPPORT FOOT	Greasing	Grease type EP Class NLGI 2	200 hours
FAN SHAFT BEARINGS SUPPORT	Change oil	Oil SAE 90	1 year



Carefully clean the greasing nipples and the oil filler in order to avoid that, during lubrication, dirt might be introduced. In the case of intensive use of the machine, reduce the lubrication intervals.




13.2 FAN SHAFT SUPPORT OIL LEVEL CHECK

1. Remove the oil filling plug with the dipstick.
2. Clean the dipstick and introduce it again.
3. Extract the dipstick and check the oil level, which has to be between the two minimum and maximum level notches of the dipstick itself.
Should it be necessary to top up the level, add some SAE 90 oil, up to reach the dipstick upper notch (MAX) with oil dipstick completely inserted.



NEVER exceed the MAX level mark of the dipstick.

4. Reintroduce the oil filling plug with the dipstick; ensure that the oil plug locked.



13.3 FAN SHAFT SUPPORT OIL REPLACEMENT



Let the fan support oil replacement intervention be carried out at a C.I.M.A. customers' service centre, or observe the regulations in force for the disposal of the used oil.

1. Remove the oil filling plug with the dipstick.
2. Remove the oil drain plug and let the oil completely flow out from the fan shaft support.
3. Check the oil drain plug and the relevant seal for integrity, replace them, if necessary, and close again the oil drain plug.
4. Through the filling pipe, pour a SAE 90 oil proper quantity, up to reach the MAX notch on the dipstick:
- 0,22 liters.




NEVER exceed the MAX level mark of the dipstick.

- Reintroduce the oil filling plug with the dipstick; ensure that the oil plug locked.

13.4 CLEANING OF FILTER'S CARTRIDGE

- Set the lever of 3-way tap (P2) to the "B" position.
- Completely close the pressure regulator, by turning clockwise the handle of the manual regulator (P5) or by turning the pressure up (keep the joystick on "+" for about 15 seconds) if the atomizer is provided with electric regulator (E5).
- Position the switches of the control electric switchboard (E10) on "OFF" or close the manual distributor's taps (P9).
- Undo the thumb screw and remove the body of the filter.
- Extract the cartridge: clean the grill and the retaining O.Ring.
- Reassemble the cartridge and secure the lid with the thumb screw. Pay attention to the O-Ring of the lower body during the assembly: the incorrect sealing of the filter will jeopardise the proper operation of the sprayer and cause loss of the mixture.




13.5 FAN BELT TENSIONER

Check length "L" of the spring (refer to Picture): it should be in tension between **9** and **12** cm..



If the fan control belt has to be replaced, the correct tensioning of the same one (spring length) has to be OBLIGATORILY checked after the first and after the second operation hour. If the value measured exceeds 12 cm, tighten the belt tightener screw, up to get the minimum length (9 cm).


The belt setting will take place within the first 2+3 operating hours; when that time has elapsed, verify the spring length, according with the time intervals (periodicity) indicated in the "Maintenance operations' table".



13.6 PUMP BELT TENSIONER

Check length "L" of the spring (refer to picture): it should be in tension between **4 and 5 cm**.

If the value measured exceeds 5 cm, tighten the belt tightener screw, up to get the minimum length (4 cm).




13.7 MAIN TANK FASTENING BELT



The adjustment of the belts takes place during the first 3÷4 hours of use of the atomizer; after this period check and restore the correct tension of the belts so that the perfect block of the main tank to the frame will be guaranteed, this way preventing any damages or breakups of the tank itself.

Check the tension of the fixing belts of the main tank to the frame. To restore the correct tension of the belts screw in the register screw (4) on both sides of the tank.



13.8 TABLE OF MAINTENANCE OPERATIONS

CHECK	SEASON START TREATMENTS	BEFORE EVERY TREATMENTS	END OF EVERY TREATMENTS	SEASON-END TREATMENT	RECOMMENDED FREQUENCY
Fan belt-tensioner spring: CHECK LENGHT 9-12 cm	YES	YES	**	**	**
Pump belt-tensioner spring: CHECK LENGHT 4 - 5 cm	YES	YES	**	**	**
Fan shaft support: CHECK OIL LEVEL	YES	YES	**	**	8 hours
Fan shaft support: CHANGE OIL	**	**	**	YES	1 year
Tank: CHECK BELT CONDITION AND PROPER TIGHTENING	YES	YES	**	**	**
Fan belt-tensioner support: GREASING	**	**	**	YES	1 year
Free wheel: GREASING	**	**	**	YES	1 year
Wheel hubs: GREASING	**	**	**	YES	200 hours
Support foot: LUBRICATING	**	**	**	YES	200 hours
Filter: CHECK CLEANING	YES	YES	YES	YES	**
Tank level gauge: CHECK CLEANING AND GOOD CONDITIONS	YES	YES	YES	YES	**
Fittings and piping: CHECK GOOD CONDITIONS	YES	YES	**	YES	**
Fixed and mobile parts, clamps and fittings: CHECK FOR INTEGRITY, PERFECT SEALING AND TIGHTENING	YES	YES	**	**	**
Frame articulated joint: GREASING	**	**	**	YES	200 hours
Drawbar eye: GREASING	**	**	**	YES	200 hours
Wheels: CHECK THE SCREW NUTS TIGHTENING AND TYRES PRESSURE	YES	YES	**	YES	**
Axle and wheel hubs: CHECK THE SCREWS AND NUTS TIGHTENING	YES	YES	**	YES	**
Hydraulic circuit and tank: COMPLETELY DRAIN AND WASH	**	**	YES	YES	**
Sprayer: EXTERIOR WASHING	**	**	YES	YES	**
Sprayer: STORAGE	**	**	**	YES	**

A. FAULT: By utilising the filler piping the pump doesn't operate (suction)



It is necessary to disengage the drive outlet (PTO) and wait for it to stop rotating before repeating the filling operation.

1. CAUSE: the quantity of water poured into the tank is insufficient to trigger the pump.
REMEDY: *Add water to the tank until the pump starts its cycle.*
2. CAUSE: the filler piping sucks in air.
REMEDY: *Completely submerge the suction filter of the filler piping.*
3. CAUSE The pump filter is clogged.
REMEDY: *Clean the filter*
4. CAUSE Lack of seal of the pipes.
REMEDY: *Check the tightening of ring nuts, fittings and clamps. Check the efficiency of sealers and that piping elements are not cracked or broken. Replace parts that are possibly found to be defective.*
5. CAUSE Slipping of the pump's belt.
REMEDY: *Check the tension of the belt-tensioner's spring. (4+5 cm).*
6. CAUSE The pump's belt might be broken.
REMEDY: *Replace the belt.*

B. FAULT: Leakage and dripping from the pump

1. CAUSE Non-sealing of the fittings and clamps connecting the piping to the pump.
REMEDY: *Check for proper tightening of ring nuts and clamps. Check the efficiency of the sealers. Replace parts that are possibly found to be defective.*
2. CAUSE Mechanical sealing defective.
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*

C. FAULT: Drop in pressure of the hydraulic circuit signalled by the gauge

1. CAUSE Dirty filter.
REMEDY: *Clean the cartridge*
2. CAUSE The pump filter is clogged.
REMEDY: *Clean the filter*
3. CAUSE: Faulty sealing of the hydraulic circuit.
REMEDY: *Check the operation of the pump and the tension of its belt. Check the proper tightening of ring nuts, fittings and clamps. Check the efficiency of the sealers and the integrity of the piping. Replace the parts that are possibly found to be defective.*
4. CAUSE: Gauge defective.
REMEDY: *Replace the pressure gauge.*
5. CAUSE: Suction or gauge connection pipe clogged.
REMEDY: *Clean.*

D.FAULT: Variations in the pressure of the hydraulic circuit (marked by the gauge)

1. CAUSE Lack of seal of the pipes and/or the valves.
REMEDY: *Check the clamping of the ring nuts, the connections and the clamps. Verify the efficiency of the gaskets and the integrity of the pipes. Replace the possibly defective parts.*
2. CAUSE: Residue of product at the entrance of the gauge
REMEDY: *Clean.*

3. CAUSE: Wrong positioning of the circuit-washer faucet (P15) with the circuit-washer tank empty.
REMEDY: *Position the lever of the faucet correctly (P15 - pos. 1") and fill the circuit-washer tank.*
 4. CAUSE: Lack of seal of the O-Ring gasket of the pump suction connection (cone).
REMEDY: *check the correct assembling and the efficiency of the O-Ring gasket, if necessary replace the gasket.*
- E. FAULT: Vibrations of fan unit.**
1. CAUSE: Dirty fan.
REMEDY: *Wash. (It is advisable to refer a C.I.M.A. point of "Sale and Service".*
 2. CAUSE: The tractor and of the atomizer PTOs are not lined up or their position determines the overcoming of the maximum work angle of the drive cardan shaft.
REMEDY: *Position the 2 PTOs so that the drive cardan shaft can work correctly (see Paragraph 5.2).*
- F. FAULT: Anomalous and continuous noisiness together with vibrations of the fan group.**
1. CAUSE: Breaking of the fan shaft bearings.
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*
 2. CAUSE: Interference fan - case.
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*
- G. FAULT: Intermittent operation of the whole distribution device**
1. CAUSE: Lack of seal of the hydraulic circuit that goes from the tank (T1) suction pipes to the electrovalves (E7) or hand distributor (P8).
REMEDY: *Carefully inspect all the points at which suction of air can take place, including as well those at which no liquid seepage is detected. Check the proper tightening of ring nuts, fittings and clamps. Check the efficiency of the sealers and the integrity of the piping. Reinstate the efficiency and replace parts that might have been found to be defective.*
- H. FAULT: Intermittent spraying only on the one side of the distribution device**
1. CAUSE: Faulty sealing of the hydraulic circuit going from the manual (P8) or electrical (E7) distributor to the distribution point involved.
REMEDY: *As per point G.1.*
- I. FAULT: No spraying action delivered: totally.**
1. CAUSE: Clogging up of the grill/filter on the pump, of the pump suction inside the tank or suction pipes of pump clogged up with deposits of hardened plant protection product.
REMEDY: *Clean.*
- J. FAULT: No spraying action delivered: totally or only on the one side of the distribution device**
1. CAUSE: Manual distributor (P8) taps dirty or clogged, or pump suction piping clogged by hardened product deposits.
REMEDY: *Clean.*
 - 1b.CAUSE: Electrical distributor (E9) taps blocked by incrustations in the closed position.
REMEDY: *Remove the cover, act on the opening/closing control rod. Clean the distributor.*

- 2b. CAUSE: Fuses of the electrical control panel (E10)
REMEDY: *Replace the fuses.*
- 3b. CAUSE: Power cable W1 of the electrical panel interrupted or oxidized connectors of the electric distributor (E9)
REMEDY: *Connect and possibly replace the defective components correctly.*
- 4. CAUSE: Defective electrical connections.
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*
- 5. CAUSE: Pump defective (only in case total delivery missing).
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*
- 6. CAUSE: Broken pump belt.
REMEDY: *Replace the belt (See Paragraph 15.1).*



THE CAUSES AND REMEDIES FOR THE FAULTS CONCERNING THE DELIVERY OF THE SPRAYING BY ONE OR MORE DIFFUSERS ARE INDICATED IN THE USE AND MAINTENANCE MANUAL OF EACH SPRAYHEAD.

K. FAULT: Anomalous consumption of oil of the fan support.

- 1. CAUSE: Oil drain plug not adequately closed.
REMEDY: *Check, reposition and adequately close then handle the filling up of the oil level.*
- 2. CAUSE: Damaged flexible oil waste pipe or damaged pipe fixing clamp.
REMEDY: *Check, adequately then handle the filling up of the oil level. Replace the damaged parts: Address a C.I.M.A. point of "Sale and Service".*
- 3. CAUSE: Drawings from the support mechanical seals.
REMEDY: *Address a C.I.M.A. point of "Sale and Service".*

L. FAULT: Noisiness (ticking) coming from the upper part of the mechanical drive at low runnings, above all when slowing down.

- 2. CAUSE: Consumption of the damping elements of the fan release.
REMEDY: *Eventually have it replaced; address a C.I.M.A. point of "Sale and Service".*

M. FAULT: Noisiness (ticking) coming from the lower part of the mechanical drive at low runnings, above all when slowing down.

- 1. CAUSE: Lack of grease in the multiplier free wheel.
REMEDY: *Grease the free wheel.*

15

REPAIRS ALLOWED

15







THE OWNER AND/OR THE OPERATOR OF THE SPRAYER ARE NOT PERMITTED TO MODIFY THE STRUCTURE OR THE SPECIFIC OPERATION OF THE SPRAYER ITSELF. ANY REPAIRING INTERVENTION HAS TO BE CARRIED OUT EITHER AT THE DEALERS' OR AT THE C.I.M.A. S.p.A. AUTHORIZED WORKSHOPS, OTHERWISE ANY KIND OF WARRANTY IMMEDIATELY CEASES AND C.I.M.A. S.p.A. IS CLEARED OF ANY CONSEQUENT AND/OR IMPLIED RESPONSIBILITY.



Stop the engine and remove the key from the tractor's control panel before any operation on the sprayer.

15.1 REPLACEMENT OF PUMP CONTROL BELT

1. Unscrew and remove the two upper screws (1) of the tank fastening bracket (2) and the relative washers.
2. Unscrew and remove the two screws (4) and the relative washers, on the right and left of the tank respectively, which fasten the lower part of the tank to the frame.
3. Remove the hand-washing tank (3).
4. Remove the fan assembly protection (6), by unscrewing the screw (5) fastening it to the frame.
5. Completely unscrew the tightener spring adjusting screw (8): the pump support plate (7) will so freely turn.
6. Remove the worn out belt (9), by getting it first loose from the pump pulley and then from the upper control pulley.



7. Insert the new belt first into the race of the upper pulley and then into the race of the pump pulley.
8. Reinstall the spring of the belt-tensioner according to the suggested tensioning conditions (see Paragraph 13.6).
9. Mount back the fan assembly protection casing.

10. Refit the hand-washing tank.



Carefully tighten the screws that were undone during the belt replacement.


15.2 REPLACEMENT OF ELECTRICAL PANEL'S FUSES

1. Replace the faulty fuse pulling out it from under-back side of control panel.

* Fuse: 10 A, delayed.




ANY OTHER INTERVENTION HAS TO BE CARRIED OUT AT A C.I.M.A. CUSTOMERS' SERVICING CENTER.



15.3 PRESSURE GAUGE REPLACEMENT

1. Unscrew and disconnect the hose-end fitting (3) from the pressure gauge union (1).
2. Unscrew the ring nut (2) and remove the pressure gauge (1).
3. Replace the faulty pressure gauge (1).
4. Fit the new pressure gauge by following the removal instructions in reverse order.



ANY OTHER INTERVENTION HAS TO BE CARRIED OUT AT A C.I.M.A. CUSTOMERS' SERVICING CENTER.

15.4 INSPECTION AND CLEANING PUMP FILTER




The pump is provided by the suction side of a filter to prevent the accidental entry of foreign bodies in the pump body, such a possibility does not constitute a hazard and can only cause damage to the impeller shown by a drop in pressure reported by gauge...

The clogging of the filter pump causing an immediate lowering of pressure delivery. If necessary check the cleanliness of the filter..

Main pump

1. Position the lever of the three-way cock (P2) in position "B".
2. For the versions fitted with spray-line rinsing tank position the lever of cock (P15) in position "c".
3. Unscrew the plug (1) and eventually remove the foreign body present in to the filter.
4. If necessary, unscrew the nuts (2) and remove the filter (4), to clean completely.
5. Replace the filter by paying attention to the conditions and the proper placement of the O.Ring (5).
6. Close the screw plug (1).
7. For the versions fitted with spray-line rinsing tank position the lever of the cock (P24) in position "a".
8. Position the lever of the three-way cock (P2) in position "A" - WORKING.



Additional agitation pump

1. Position the lever of the three-way cock (P12) in position "C".
2. Close the cock (P18): position "c".
3. Unscrew the plug (1) and eventually remove the foreign body present in to the filter.
4. If necessary, unscrew the nuts (2) and remove the filter (4), to clean completely.
5. Replace the filter by paying attention to the conditions and the proper placement of the O.Ring (5).
6. Close the screw plug (1).
7. Open the cock (P18): position "a".
8. Position the lever of the three-way cock (P12) in position "A".

15.5 TANK LEVEL GAUGE CLEANING

1. With a suitable pliers release the clamp (1 and 2) fixing transparent tube of the level gauge.
2. Take off and remove the transparent tube (3).
3. Remove the red plastic ball (4) .
4. Clean, with clean water, the transparent tube both in and outside.




Gather the rinsing water in a proper container provided to be waste according to the rules or used again, putting it in the tank, for a next treatment if suitable with the product to be used.

5. If the cleaning is not satisfactory, replace the transparent tube (3).



Waste the transparent tube according to the same method as per the pesticides container.

6. Put the red plastic ball (4) into the transparent tube (3).
7. Install the transparent tube (3) making slip it on the rubber fittings.
8. Place the clamps (1 and 2) fixing the transparent tube (3) of the level gauge and close them with a suitable pliers.




15.6 CHECK HYDRAULIC DELIVERY

THE CHECK IS CONSIDERED TO BE SUCCESSFUL (THE MACHINE IS PROPERLY CALIBRATED) WHEN THE CALCULATED VALUE “Q” CORRESPONDS TO THE VALUE INDICATED ON THE “FLOW CHART” TABLE WITH A $\pm 2.5\%$ TOLERANCE.

If the resulting values are different, check the efficiency of the pipes, the fittings, the pressure gauge and the correct positioning of the calibration discs (P11). If necessary, replace the damaged or defective parts and repeat the test.

15.6.1 Check with flowmeter

1. Disengage the fan (for versions where it is foreseen): see Paragraph 8.1.a.
2. Fill the tank with enough clean water to make the test.
3. Turn the 3-way valve (P2) to “B” position (Maintenance).
4. Disconnect the pipe (T4) from the electrical distributor (E9) or from manual distributor (P9).
5. Connect the appropriate flowmeter for the measurements to be made, between the pipe (T4) and the electrical distributor (E9) or the manual distributor (P9). If necessary, remove the fitting (P26) and use the fittings suitable for connecting the flowmeter.



6. Turn the 3-way valve (P2) to “A” position (Work - phytosanitary products distribution).
7. Engage the fan (for versions where it is foreseen): see Paragraph 8.1.b..



The declared performance is achieved with the PtO at 540 rpm and with the fan running. For a correct result of the check, this condition MUST ALWAYS BE RESPECTED.

8. Run the PtO at 540 rpm.
9. Open the taps of the 2-way distributor:
 - a. if electric (E10), set the switches to “ON”
 - b. if manual (P9) turn the levers vertically
10. Adjust the working pressure by using the manual pressure regulator (P5) (or the electric one E5) and the position of the calibration disc (P11) according to indications given on the “flow charts” for the distribution device (sprayhead) used.
11. Take the flow rate per hour

15.6.2 Check without flowmeter



TESTING OF HYDRAULIC DELIVERY MUST BE MADE WITH THE SPRAYER ON A FLAT SURFACE. THE PROOF IS IN THE DETECTION OF TIME TO PROVIDE A KNOWN QUANTITY CONTENT OF LIQUID IN TANK.

1. Disengage the fan (for versions where it is foreseen): see Paragraph 8.1.a.
2. Close the taps of the 2-way distributor:
 - a. if manual (P9), the levers are to be lowered (horizontally positioned);
 - b. if electric, position to "OFF" the quick-break switches (E10).
3. Fill the tank with about 250 liters of clean water (**USED AS REFERENCE THE MARK OF LEVEL INDICATOR ON THE TANK** - see Paragraphs 8.2/8.3).
4. Engage the fan (for versions where it is foreseen): see Paragraph 8.1.b.



The claimed performance is obtained with the PTO at 540 rpm. and with the fan running . For correct verification result this condition MUST ALWAYS BE RESPECTED.

5. Bring the PTO to 540 rpm rotation rate.
6. Open the taps of the 2-way distributor:
 - a. if manual (P9), the levers are to be raised (vertically positioned);
 - b. if electric, position to "ON" the quick-break switches (E10).
7. Regulate the operating pressure, by acting on the pressure regulator (P5) (or electric E5) with the distributor, hand (P9) or electric (E9), open (DISTRIBUTION) and regulate the position of calibration disc (P11) in accord to "Delivery chart" relating to the sprayhead used.
8. Close the taps of the 2-way distributor:
 - a. if manual (P9), the levers are to be lowered (horizontally positioned);
 - b. if electric, position to "OFF" the quick-break switches (E10).
9. Add water to the tank until you reach the mark of 300 liters (reference).
10. Add additional 25 liters of water to the tank, the quantity required for the verification flow, using a graduated container or by weighing the amount payable (1liter = 1 kg).
11. Open the taps of the 2-way distributor (manual or electric) to start delivery.
12. Continue the delivery until the water reaches the mark 300 liters on the level indicator.



NOTED THE TIME ELAPSED BETWEEN THE RELEASE DELIVERY AND THE ACHIEVEMENT OF MARK 300 LITERS.

13. Take the flow rate per hour:

apply the formula
$$Q = \left(\frac{60}{t} \right) \times 25$$
 where: Q, is the hourly delivery detected (lt./h);
t, is the time measured in minutes and seconds (centesimal).

15.7 TANK REMOVAL OR REPLACEMENT




This operation has to be carried out by a C.I.M.A. service point.



The operation has to be carried out by complete absence of liquid residuals both inside the tank and in the hydraulic circuit.

1. Make the tank free from all the hydraulic and pneumatic connections.
2. Loosen the screw nut (4), for tensioning the tank fastening belt.
3. Remove the split pin (3).
4. Unscrew the belt end (2), in order to make the tank free; carry out the same operation for the second belt (1).
5. Lift the tank and remove it from the frame..



Before reassembling the main tank check the integrity of the rubber supports glued on the frame; if damaged or particularly worn replace them.

6. Position the tank on the frame.
7. Reposition the anchorage belts in their own seats.
8. Screw the regulation nut on each belt so that they are tight enough to firmly secure the tank to the frame.
9. Replace both the safety pins.



The adjustment of the belts takes place during the first 3-4 hours of use of the atomizer; after this period check and restore the correct tension of the belts so that the perfect block of the main tank to the frame will be guaranteed, this way preventing any damages or breakups of the tank itself.



Before every treatment, check the tension of the tank anchorage belts

15.8 REPLACEMENT LAMPS REARLIGHTS

(for versions in which is envisaged)




Before working on the electric system disconnect the Standard 7 pin plug from the tractor.

1. Loosen the glass fixing screws (1) of the rear light.
2. Remove the screws (1) and the glass (2).
3. Replace the non-functioning lamp.

For the replacement you must use:


- use a lamp ECE P21W 12V for direction indicator (5)
- use a lamp ECE P21W 12V for brake light (4)
- use a lamp ECE C5W 12V for rear light (3)

4. Install the new lamp, check functional, allow install the glass (2) and block it with fixing screws (1).



16 INTEGRATIVE DIAGRAMS 16


16.1 HYDRO-PNEUMATIC DIAGRAM



Legend
P - E = hydraulic circuit components
T = piping
* = for versions with rinsing tank
▲ = for versions in which this is envisaged
□ = optional on demand

01728_1

Versions with additional agitation pump




Legenda
 P - E = hydraulic circuit components
 T = piping
 * = for versions with rinsing tank

▲ = for versions in which this is envisaged
 □ = optional on demand

01728_2

E.P.A. versions



Legenda

P - E = hydraulic circuit components

T = piping


* = for versions with rinsing tank

▲ = for versions in which this is envisaged

◻ = optional on demand

01728_3

E.P.A. versions with additional agitation pump





Legend
P - E = hydraulic circuit components
T = piping
***** = for versions with rinsing tank

▲ = for versions in which this is envisaged
 □ = optional on demand


01728_4

16.2 WIRING DIAGRAM





01670_EN1
DIS.N. 910233


Wiring diagram - standard versions




Wiring diagram - versions with electric pressure regulator and electric cylinder for sprayhead movements




01E70_3



Wiring diagram - upper cannons delivery control panel




Wiring diagram - control panel for sprayhead movement (3 electrovalves assembly)



Wiring diagram for rear lights

Sprayer Model	Observed equivalent average level L_{qA} - dB(A)
Link 50	93 ± 0,2
Link 50 Super	93 ± 0,2
Link 55	95,4 ± 0,2
Link 55 Super	95,4 ± 0,2
Link 55 Extra	95.4 ± 0,2

18 ATTACHMENT: DECLARATON OF CONFORMITY 18



DICHIARAZIONE DI CONFORMITÀ

ai sensi della Direttiva 2006/42/CE come emendata dalla Direttiva 2009/127/CE e successive modificazioni

<p style="text-align: center;">DECLARATION OF CONFORMITY as Directive 2006/42/EC as amended by the Directive 2009/127/EC and subsequent modifications</p>	<p style="text-align: center;">DECLARATION DE CONFORMITE selon la Directive 2006/42/CE comme modifiée depuis la Directive 2009/127/CE et modifications ultérieures</p>
<p style="text-align: center;">ÜBEREINSTIMMUNGS-ERKLÄRUNG II. Direktiven 2006/42/CE wie abändert von den Direktiven 2009/127/CE und nachfolgenden Änderung</p>	<p style="text-align: center;">DECLARACION DE CONFORMIDAD de la Directiva 2006/42/CE según la Directiva 2009/127/CE y sus modificaciones siguientes</p>

CIMA S.p.A. - 27040 Montù Beccaria - Loc. Molino Quaroni - (PV) - ITALIA
<http://www.cima.it> - e-mail: info@cima.it - Tel. +39 0345 246636 - Fax +39 0365 246637

DICHIARA TUTTO LA PROPRIA RESPONSABILITÀ CHE LA MACCHINA	HERE WITH DECLARES UNDER THEIR PERSONAL RESPONSIBILITY THE FOLLOWING MACHINE	DECLARATIONS SOUS LEUR PROPRIE RESPONSABILITÉ LA MACHINE DE SUIVE CHAPITRE	ERKLÄRT HIERMIT UNTER SEINER PERSÖNLICHEN VERANTWORTUNG DASS DIE MASCHINE	DECLARA BAJO DE LA PROPIA RESPONSABILIDAD QUE LA MÁQUINA
--	--	--	---	--

SERIE, TIPO, MODEL TYPE, SERIAL, TYPE, MODEL, SERIAL NO.

RESERVED


<p style="text-align: center;">MATRICOLA / SERIAL - MATR. / RICULE / SERIAL - MATR. / RIGULA NR.</p>			
---	--	--	--

<p>È conforme ai Requisiti essenziali di Sicurezza e di Tutela della Salute di cui alla Direttiva:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 e successive modificazioni.</p> <p>Per la verifica della Conformità di cui alle stesse norme menzionate, sono state consultate le seguenti Norme armonizzate:</p> <p>EN 13857 EN 349 EN 4254-1 e EN 4254-6</p>	<p>Conforme to the essential Safety regulations as well as the Health requirements set per European Community Directives:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 et modifications ultérieures.</p> <p>Pour vérifier la conformité aux directives mentionnées, ont été prises en compte les Normes harmonisées suivantes:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>	<p>Conforme aux exigences de Sécurité et de Sauvegarde de la Santé énoncées à la Directive:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 et modifications ultérieures.</p> <p>Pour vérifier la conformité aux directives mentionnées, ont été prises en compte les Normes harmonisées suivantes:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>	<p>Stimmt mit den wesentlichen Anforderungen der Sicherheitsvorschriften und der Gesundheitsvorschriften der Europäischen Gemeinschaft II. EWG-Direktive Nr.:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 und nachfolgenden Änderungen.</p> <p>Für die Überprüfung dieser Übereinstimmungs-Erklärung, die obigen Direktiven sind folgende Normen konsultiert worden:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>
--	--	--	---


<p>Conforme con los requisitos esenciales de Seguridad y de Preservación de la Salud contenidos en las Directiva:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 y modificaciones siguientes.</p> <p>Para comprobar la conformidad a la que se refieren las Directivas anteriormente citadas, se han consultado las siguientes Normas Armonizadas:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>	<p>Conforme to the essential Safety regulations as well as the Health requirements set per European Community Directives:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 et modifications ultérieures.</p> <p>Pour vérifier la conformité aux directives mentionnées, ont été prises en compte les Normes harmonisées suivantes:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>	<p>Conforme aux exigences de Sécurité et de Sauvegarde de la Santé énoncées à la Directive:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 et modifications ultérieures.</p> <p>Pour vérifier la conformité aux directives mentionnées, ont été prises en compte les Normes harmonisées suivantes:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>	<p>Stimmt mit den wesentlichen Anforderungen der Sicherheitsvorschriften und der Gesundheitsvorschriften der Europäischen Gemeinschaft II. EWG-Direktive Nr.:</p> <p>2006/42/CE - 17/05/2006 2009/127/CE - 21/10/2009 und nachfolgenden Änderungen.</p> <p>Für die Überprüfung dieser Übereinstimmungs-Erklärung, die obigen Direktiven sind folgende Normen konsultiert worden:</p> <p>EN 13857 EN 349 EN 4254-1 et EN 4254-6</p>
--	--	--	---

Responsabile della Sicurezza e del Fascicolo Tecnico - The Security and Technical File Official - Responsable Sécurité, Homologation et Dossier Technique - Der Technisch Dossier und Sicherheits-Bestirmer - Responsable de la Seguridad y del Fascículo Técnico

Smeraldi Paolo



Montù Beccaria (PV) - Italy
Data: Date, Datum, Fecha



Atomizzatori e Impolveratori
CIMA S.p.A. - 27040 Montù Beccaria - Loc. Molino Quaroni - (PV) Italy



THE OWNER AND/OR THE OPERATOR OF THE SPRAYER ARE NOT PERMITTED TO MODIFY THE STRUCTURE OR THE SPECIFIC OPERATION OF THE SPRAYER ITSELF. ANY REPAIRING INTERVENTION HAS TO BE CARRIED OUT EITHER AT THE DEALERS' OR AT THE C.I.M.A. S.p.A. AUTHORIZED WORKSHOPS, OTHERWISE ANY KIND OF WARRANTY IMMEDIATELY CEASES AND C.I.M.A. S.p.A. IS CLEARED OF ANY CONSEQUENT AND/OR IMPLIED RESPONSIBILITY.

19.1 GENERAL INFORMATION

The goods sold are covered by a general warranty that ensures the good quality of the materials, solid construction and regular operation for twelve months from the date of delivery.

During the warranty period, C.I.M.A. S.p.A. pledges to replace, free of charge, the parts which, in his unquestionable judgement, are considered defective, provided that the flaws and defects cannot be attributed to poor use or maintenance of the product or an unreasonable, inappropriate and unsuitable use of such product with respect to the technical instructions supplied by C.I.M.A. S.p.A.

The products which have been modified, repaired, assembled or tampered with by a third party, consumption materials and the parts subject to wear and tear are excluded from the warranty.

The replacements will be made free CIMA S.p.A. works and the buyer will be responsible for all shipping and return expenses.

The buyer will be responsible for the costs of the labour needed to replace the parts considered defective. The resolution of the contract and any compensation for damage cannot be claimed by the buyer except for serious faults to be proven by said buyer.

The warranty will no longer be extended to the buyer if he does not respect the agreed upon payment procedures and terms.

19.2 REPORTING DEFECTS IN GOODS

The claims for flaws or defects in the goods shall be submitted within eight days from when such goods are received or from when hidden defects are discovered, in writing, by means of a registered letter.

No claim can be made, nor as an exception, in a court of law if the goods, for which the claim is submitted, have not been regularly paid.

Any claim concerning a single delivery of goods will not exonerate the buyer from his obligation to pick-up the remaining quantity of goods within the limit of the order.

19.3 TO PASS SAFETY INFORMATION

The buyer is responsible towards the final user for the safety information shown on the sale documentation, concerning use limit, performances and product features.

19.4 VALIDITY AND ACCEPTANCE

The warranty is valid if the CERTIFICATE OF WARRANTY is sent, to C.I.M.A. S.p.A., with every part of it filled in, within 30 days from the date of purchase (referring to the date of the postmark).

WARRANTY CERTIFICATE

Copy for the owner (to be kept in the manual "Operation an maintenance instructions").

Owner's Name:.....

Company Name:.....

Address:

City: State: Postcode:


Email: Tel. No:.....

Date of Purchase:..... Invoice No:.....

Machine Model: Serial No:.....

Sprayhead Model:

Authorized Dealer's Stamp (compulsory)



PRIVACY

Consent to the use of personal data

"In compliance with the Italian legislative Decree no. 196 dated 30/06/2003, I hereby authorize C.I.MA. S.p.A. to use and process my personal details contained in this document."

Date..... Signature.....

Warranty conditions

1. Warranty

The goods sold are covered by a general warranty that ensures the good quality of the materials, solid construction and regular operation for twelve months from the date of delivery.

During the warranty period, C.I.M.A. S.p.A. pledges to replace, free of charge, the parts which, in his unquestionable judgement, are considered defective, provided that the flaws and defects cannot be attributed to poor use or maintenance of the product or an unreasonable, inappropriate and unsuitable use of such product with respect to the technical instructions supplied by C.I.M.A. S.p.A. The products which have been modified, repaired, assembled or tampered with by a third party, consumption materials and the parts subject to wear and tear are excluded from the warranty. The replacements will be made free CIMA S.p.A. works and the buyer will be responsible for all shipping and return expenses. The buyer will be responsible for the costs of the labour needed to replace the parts considered defective. The resolution of the contract and any compensation for damage cannot be claimed by the buyer except for serious faults to be proven by said buyer. The warranty will no longer be extended to the buyer if he does not respect the agreed upon payment procedures and terms.

2. Reporting defects in goods

The claims for flaws or defects in the goods shall be submitted within eight days from when such goods are received or from when hidden defects are discovered, in writing, by means of a registered letter.

No claim can be made, nor as an exception, in a court of law if the goods, for which the claim is submitted, have not been regularly paid.

Any claim concerning a single delivery of goods will not exonerate the buyer from his obligation to pick-up the remaining quantity of goods within the limit of the order.

3. To pass safety information

The buyer is responsible towards the final user for the safety information shown on the sale documentation, concerning use limit, performances and product features.

4. Validity and acceptance

The guarantee is valid if the CERTIFICATE OF GUARANTEE is sent, to C.I.M.A. S.p.A., with every part of it filled in, within 30 days from the date of purchase (referring to the date of the postmark).

Informative according to the D. L. n. 196 of the 2003 (“Code in matter of protection of the personal data”)

Dear customer,
according to art. 13 of the D.Lgs. 196/03 “Unique Text on Privacy” (referred to as ‘Law’ here below) we would like to inform you about the following:

- 1) the personal data given to C.I.M.A. S.p.A. when filling in the “Warranty Certificate” will be processed respecting the above mentioned regulations and the rules of privacy stated there in;
- 2) according to art.4, paragraph 1, lett. a) of the Law, the handling of personal data signifies “whatever operation or set of operations carried out (even without the aid of electronic instruments) regarding the collection, recording, organization, conservation, research, handling, modification, selection, extracting of details, comparison of, use of, connecting to, blockage, passing on, distributing, cancellation and destruction of data, even if not recorded in a data bank”;
The handling of the personal data given is carried out by automatized and non automatized instruments, with controlled access and as specified by clause B of the Law;
- 3) the data are processed to an institutional end, in connection with or useful to the activities of C.I.M.A. S.p.A. for filing, processing and management;
- 4) the data are collected and recorded so that access is only allowed to authorized persons and they may be processed exclusively by C.I.M.A. S.p.A. to the above mentioned end;
- 5) the collected data may only be given to a third party exclusively in connection with accounting imposed by fiscal law and in the case of demands from the judicial authority.

In addition we inform you that any interested party may exercise his rights mentioned in art.7 of the Law; in the exercise of such rights the interested party may delegate or give a proxy, in writing, to persons or associations. The authority to carry out this processing is C.I.M.A. S.p.A., represented in person by a lawyer.

The data processing is done by instruments fit to guarantee the safety and privacy as specified in clause B of the Law.



WARRANTY CERTIFICATE

This warranty is valid only when this registration form is completed and returned, within thirty (30) days from the date of purchase, to the following address:

C.I.M.A. S.p.A. - Loc.Molino Quaroni - 27040 Montù Beccaria - (PV) - Italy
or sent by fax to the number +39.0385.246637 or by email to: info@cima.it

Owner's Name:

Company Name:

Address:

City: State: Postcode:

Email: Tel. No:

Date of Purchase: Invoice No:

Machine Model: Serial No:

Sprayhead Model:

Authorized Dealer's Stamp (compulsory)

PRIVACY

Consent to the use of personal data

"In compliance with the Italian legislative Decree no. 196 dated 30/06/2003, I hereby authorize C.I.M.A. S.p.A. to use and process my personal details contained in this document."

Date Signature

cut along the dotted line

Warranty conditions

1. Warranty

The goods sold are covered by a general warranty that ensures the good quality of the materials, solid construction and regular operation for twelve months from the date of delivery.

During the warranty period, C.I.M.A. S.p.A. pledges to replace, free of charge, the parts which, in his unquestionable judgement, are considered defective, provided that the flaws and defects cannot be attributed to poor use or maintenance of the product or an unreasonable, inappropriate and unsuitable use of such product with respect to the technical instructions supplied by C.I.M.A. S.p.A. The products which have been modified, repaired, assembled or tampered with by a third party, consumption materials and the parts subject to wear and tear are excluded from the warranty. The replacements will be made free CIMA S.p.A. works and the buyer will be responsible for all shipping and return expenses. The buyer will be responsible for the costs of the labour needed to replace the parts considered defective. The resolution of the contract and any compensation for damage cannot be claimed by the buyer except for serious faults to be proven by said buyer. The warranty will no longer be extended to the buyer if he does not respect the agreed upon payment procedures and terms.

2. Reporting defects in goods

The claims for flaws or defects in the goods shall be submitted within eight days from when such goods are received or from when hidden defects are discovered, in writing, by means of a registered letter.

No claim can be made, nor as an exception, in a court of law if the goods, for which the claim is submitted, have not been regularly paid.

Any claim concerning a single delivery of goods will not exonerate the buyer from his obligation to pick-up the remaining quantity of goods within the limit of the order.

3. To pass safety information

The buyer is responsible towards the final user for the safety information shown on the sale documentation, concerning use limit, performances and product features.

4. Validity and acceptance

The guarantee is valid if the CERTIFICATE OF GUARANTEE is sent, to C.I.M.A. S.p.A., with every part of it filled in, within 30 days from the date of purchase (referring to the date of the postmark).

Informative according to the D. L. n. 196 of the 2003 (“Code in matter of protection of the personal data”)

Dear customer,

according to art. 13 of the D.Lgs. 196/03 “Unique Text on Privacy” (referred to as ‘Law’ here below) we would like to inform you about the following:

1) the personal data given to C.I.M.A. S.p.A. when filling in the “Warranty Certificate” will be processed respecting the above mentioned regulations and the rules of privacy stated there in;

2) according to art.4, paragraph 1, lett. a) of the Law, the handling of personal data signifies “whatever operation or set of operations carried out (even without the aid of electronic instruments) regarding the collection, recording, organization, conservation, research, handling, modification, selection, extracting of details, comparison of, use of, connecting to, blockage, passing on, distributing, cancellation and destruction of data, even if not recorded in a data bank”;

The handling of the personal data given is carried out by automatized and non automatized instruments, with controlled access and as specified by clause B of the Law;

3) the data are processed to an institutional end, in connection with or useful to the activities of C.I.M.A. S.p.A. for filing, processing and management;

4) the data are collected and recorded so that access is only allowed to authorized persons and they may be processed exclusively by C.I.M.A. S.p.A. to the above mentioned end;

5) the collected data may only be given to a third party exclusively in connection with accounting imposed by fiscal law and in the case of demands from the judicial authority.

In addition we inform you that any interested party may exercise his rights mentioned in art.7 of the Law; in the exercise of such rights the interested party may delegate or give a proxy, in writing, to persons or associations. The authority to carry out this processing is C.I.M.A. S.p.A., represented in person by a lawyer.

The data processing is done by instruments fit to guarantee the safety and privacy as specified in clause B of the Law.

Where we are



cima[®]



Loc. Molino Quaroni n.7, Montù Beccaria - PV - (ITALY)
Tel. +39.0385.246636 - www.cima.it